

MZ-R50

SERVICE MANUAL

*US Model
Canadian Model
AEP Model
UK Model
E Model
Australian Model
Tourist Model*



US and foreign parts licensed Dolby Laboratories Licensing Corporation.

Model Name Using Similar Mechanism	NEW
MD Mechanism Type	MT-MZR-50-143
Optical Pick-up Type	KMS-280A

SPECIFICATIONS

System

Audio playing system
MiniDisc digital audio system
Laser diode properties
Material: GaAlAs
Wavelength: $\lambda = 780 \text{ nm}$
Emission duration: continuous
Laser output: less than $44.6 \mu\text{W}$
(This output is the value measured at a distance of 200 mm from the lens surface on the optical pick-up block with 7 mm aperture.)
Recording and playback time
Maximum 74 minutes (MDW-74, stereo recording)
Maximum 148 minutes (MDW-74, monaural recording)
Revolutions
400 rpm to 900 rpm (CLV)
Error correction
Advanced Cross Interleave Reed Solomon Code (ACIRC)
Sampling frequency
44.1 kHz
Sampling rate converter
Input: 32 kHz / 44.1 kHz / 48 kHz
Coding
Adaptive Transform Acoustic Coding (ATRAC)
Modulation system
EFM (Eight to Fourteen Modulation)
Number of channels
2 stereo channels
1 monaural channel

Frequency response
20 to 20,000 Hz $\pm 3 \text{ dB}$
Wow and Flutter
Below measurable limit
Inputs
Microphone: stereo mini-jack, 0.22-0.78 mV
Line in: stereo mini-jack, 69-194 mV
Optical (Digital) in: optical (digital) mini-jack
Outputs
Headphones: stereo mini-jack, maximum output level 5 mW+ 5 mW, load impedance 16 ohm
Line out: stereo mini-jack, 194 mV, load impedance 10 kilohm

General

Power requirements
Sony AC Power Adaptor (supplied)
connected at the DC IN 6 V jack:
120 V AC, 60 Hz (US, Canadian model)
220-230 V AC, 50/60 Hz (AEP model)
230-240 V AC, 50/60 Hz (UK, Hong Kong model)
240 V AC, 50/60 Hz (Australian model)
100-240 V AC, 50/60 Hz (E, Tourist model)
Lithium ion rechargeable battery LIP-8 (supplied)
Two LR6 (size AA) alkaline batteries (not supplied)

– Continued on page 2 –

PORTABLE MINIDISC RECORDER



SONY®

Battery operation time
See "Battery life"
Battery life

Batteries	Recording	Playback
LIP-8 lithium ion Rechargeable battery	Approx. 4 hours	Approx. 7 hours
Two LR6 (size AA) Sony alkaline dry batteries		Approx. 12 hours
LIP-8 + Two LR6 (size AA)		Approx. 22 hours

Dimensions

Approx. 109.5 x 19.7 x 77 mm (w/h/d)
(4 3/8 x 25/32 x 3 1/8 in.)

Mass


Approx. 190 g (6.8 oz) the recorder only
Approx. 240 g (8.5 oz) incl. a recordable MD,
and LIP-8 lithium ion rechargeable battery

Supplied accessories

AC power adaptor (1)
Headphones with a remote control (1)
LIP-8 lithium ion rechargeable battery (1)
Dry battery case (1)
Ear pads (2)
Carrying case (1)

Design and specifications are subject to change without notice.

For customers in Europe



This MiniDisc Recorder is classified as a CLASS 1 LASER product. The CLASS 1 LASER PRODUCT label is located on the bottom exterior.

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Caution

The use of optical instruments with this product will increase eye hazard.

Information

IN NO EVENT SHALL SELLER BE LIABLE FOR ANY DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM ANY DEFECTIVE PRODUCT OR THE USE OF ANY PRODUCT.

"MD WALKMAN" is a trademark of Sony Corporation.

TABLE OF CONTENTS

Specifications	1
1. SERVICING NOTE	3
2. GENERAL	
Location and Function of Controls	4
3. DISASSEMBLY	
3-1. Upper Panel Assy, Bottom Panel Assy Removal	20
3-2. Main Board Removal	21
3-3. Mechanism Deck (MT-MZR50-143) Removal	21
3-4. Optical Pick-up Assy, REC Board Removal	22
3-5. CLV Board Removal	22
3-6. Battery Case Assy Removal	23
3-7. Power Board, Switch Board Removal	23
3-8. Switch Unit (with JOG Dial) Removal	24
4. TEST MODE	25
5. ADJUSTMENTS	31
6. DIAGRAMS	
6-1. Explanation of IC Terminals	35
6-2. Block Diagrams	39
6-3. Circuit Boards Location	43
6-4. Printed Wiring Boards – Main Section –	45
6-5. Schematic Diagram – Main (1/3) Section –	49
6-6. Schematic Diagram – Main (2/3) Section –	53
6-7. Schematic Diagram – Main (3/3) Section –	57
7. EXPLODED VIEWS	
7-1. Upper Panel, Bottom Panel Section	65
7-2. Chassis Section	66
7-3. Mechanism Deck Section	67
8. ELECTRICAL PARTS LIST	68

Flexible Circuit Board Repairing

- Keep the temperature of the soldering iron around 270°C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.

Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

SAFETY-RELATED COMPONENT WARNING!!


COMPONENTS IDENTIFIED BY MARK \triangle OR DOTTED LINE WITH MARK \triangle ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE \triangle SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SECTION 1 SERVICING NOTE


When repairing this device with the power on, if you remove the main board or open the upper panel assembly, this device stops working. In this case, you can work without the device stopping by fastening the hook of the Open/Close detection switch (S817) with tape



Looking at the controls


See pages in () for more details.

The recorder




- | | |
|---|---|
| <p>1 Battery compartment (at the bottom) (25)</p> <p>2 MODE button (17)</p> <p>3 DISPLAY button (14, 19)</p> <p>4 CLOCK SET button (at the bottom) (16)</p> <p>5 MIC SENS switch (at the bottom) (12)</p> <p>6 AVLS switch (at the bottom) (18)</p> <p>7 DC IN 6V jack (at the rear) (6)</p> <p>8 Display window (14, 19)</p> <p>9 SYNCHRO REC (synchro-recording) switch (11)</p> <p>10 MIC (PLUG IN POWER) jack (12)</p> <p>11 LINE IN (OPTICAL) jack (6, 11)</p> <p>12 LINE OUT jack (20)</p> <p>13 DIGITAL MEGA BASS button (18)</p> | <p>14 (headphones)/REMOTE jack (8)</p> <p>15 REC indicator (14)</p> <p>16 Vertical jog dial (17, 23)</p> <p>17 TITLE/ENTER button (23)</p> <p>18 ► (play) button (7, 9)</p> <p>19 ◀◀/▶▶ (search / AMS) button (7, 9)</p> <p>20 ■ (stop) button (7, 9)</p> <p>21 VOLUME +/- button (9)</p> <p>22 HOLD switch (20)</p> <p>23 ERASE button (21)</p> <p>24 T MARK button (22)</p> <p>25 END SEARCH button (7)</p> <p>26 REC (record) switch (7)</p> <p>27 ■■ (pause) button (7, 9)</p> <p>28 OPEN button (6)</p> |
|---|---|

The display window




- 1** Position pointer (14, 19)
Shows the current location on the MD. The point under recording or playing flashes. The recorded portion lights up.



- 2** MONO (monaural) indication
3 Play mode indication
Shows the play mode of the MD.
4 Disc indication
Shows that the disc is rotating for recording, playing or editing an MD.
5 SYNC (synchro-recording) indication
6 REC indication (7)
Lights up while recording. When flashing, the recorder is in record standby mode.

- 7** Level meter
Shows the volume of the MD being played or recorded.
8 AM/PM indication (16)
Lights up along with the time indication in the 12-hour system.
9 Mega bass indication (18)
10 Battery indication (25)
Shows battery condition.
11 REMAIN (remaining time/tracks) indication (14, 19)
Lights up along with the remaining time of the track, the remaining time of the MD, or the remaining number of tracks.
12 REC DATE (recorded/current date) indication
Lights up along with the date and time the MD was recorded. When only "DATE" lights up, the current date and time are displayed.
13 Time display (14, 19)
Shows the recorded time, current time, elapsed time of the track or MD being recorded or played.
14 Character information display (14, 19)
Displays the disc and track names, date, error messages, track numbers, etc.

The headphones with a remote control




- 1** Headphones
Can be replaced with optional headphones.
2 Stereo mini plug
3 ■ (stop) button (7,9)
4 Control (9)
To play, turn to ►►► during stop. Turn to ►►►► during play to search the beginning of the succeeding track; hold in this position to fast-forward. Turn to ◀◀◀ during play to search the beginning of the preceding track; hold in this position to rewind.
5 HOLD switch (20)
Slide to lock the controls of the remote control.
6 ■■ (pause) button (7,9)
7 PLAY MODE button (17)
8 DISPLAY button (15, 19)
9 VOL (volume) +/- buttons (9)
10 TRACK MARK button (22)
11 Display window (15, 19)

Recording an MD right away!


Sound from CD players, cassette recorders, etc., will be sent analogically, but recorded digitally, in stereo. To record from a digital source, see "Recording with digital input" (page 11).

1 Make connections.




*Use the connecting cords without an attenuator. To connect to a portable CD player having a stereo mini-jack, use the RK-G136 connecting cord (not supplied).

2 Insert a recordable MD.




① Slide OPEN and open the lid.



② Insert a recordable MD with the label side facing up, and press the lid down to close.

3 Record an MD.



- ① Press and slide REC to the right. "REC" lights up and recording starts.
- ② Play the CD or tape you want to record.

To stop recording, press ■. "Data Save" or "Toc Edit" flashes while data of the recording (the track's start and end points, etc.) is being recorded. Do not move or jog the recorder or disconnect the power source while the indication is flashing in the display.

To	Press
Pause	¹⁾ Press again to resume recording.
Record from the end of the previous recording.	END SEARCH and slide REC.
Record partway through the previous recording.	▶, ▶▶ or ◀◀ to find the start point of recording and press ■ to stop. Then slide REC.
Remove the MD.	■ and open the lid. ²⁾

¹⁾ A track mark is added at the point where you press ||; thus the remainder of the track will be counted as a new track.
²⁾ Once you open the lid, the point to start recording will change to the beginning of the first track. Check the point to start recording on the display.

- If the recording does not start**
- Make sure the recorder is not locked (page 20).
 - Make sure the MD is not record-protected (page 28).
 - Premastered MDs cannot be recorded over.


For models supplied with the AC plug adaptor
 If the AC power adaptor does not fit the wall outlet, use the AC plug adaptor.

- 💡**
- The level of the recorded sound is adjusted automatically.
 - You can monitor the sound being recorded. Connect the supplied headphones with remote control to ⏸/REMOTE and adjust the volume by pressing VOLUME +/- (VOL +/- on the remote control). This does not affect the recording level.


Playing an MD right away!

To use the recorder on a rechargeable battery or dry batteries, see "Power Sources" (pages 25, 26).


1 Make connections.



2 Insert an MD.



3 Play an MD.



- ① Press **▶▶▶▶** (Turn the control to **▶▶▶▶▶▶▶▶▶▶** on the remote control).
A short beep sounds in the headphones.
 - ② Press **VOLUME (VOL on the remote control) +/-** to adjust the volume.
The volume will be shown in the display.
- To stop play, press **■**.
A long beep sounds in the headphones.

To	Press (Beeps in the headphones)
Pause	 (Continuous short beeps) Press again to resume play.
Find the beginning of the current track	◀◀ once (Turn the control to ◀◀ on the remote control) (Three short beeps)
Find the beginning of the next track	▶▶ once (Turn the control to ▶▶▶▶▶▶▶▶▶▶ on the remote control) (Two short beeps)
Go backwards while playing ¹⁾	keep pressing ◀◀ (Turn and hold the control to ◀◀ on the remote control)
Go forward while playing ¹⁾	keep pressing ▶▶ (Turn and hold the control to ▶▶▶▶▶▶▶▶▶▶ on the remote control)
Remove the MD	■ and open the lid. ²⁾

¹⁾ To go backward or forward quickly without listening, press **||** and keep pressing **◀◀** or **▶▶**.
²⁾ Once you open the lid, the point to start play will change to the beginning of the first track.

If the play does not start

Make sure the recorder is not locked (page 20).

When using optional headphones

Use only headphones with stereo mini plugs. You cannot use headphones with micro plugs.



Playback will switch automatically between stereo and monaural according to the sound source.

► Various ways of recording

Two ways of connecting to a sound source

The input jack of this recorder works as both digital and analog input jacks. Connect the recorder to a CD player or a cassette recorder using either digital input or analog input. To record, see "Recording with digital input" (page 11) to record using digital input, and "Recording an MD right away!" (page 6) to record using analog input.

Difference between digital and analog inputs

Difference	Input	Digital input	Analog (line) input
Connectable source		Equipment with an optical digital output jack	Equipment with an analog (line) output jack
Usable cord		Digital cable (with an optical or an optical-mini plug)	Line cable (with 2 phono plugs or a stereo-mini plug)
Signal from the source		Digital	Analog Even when a digital source (such as a CD) is connected, the signal sent to the recorder is analog.
Recorded track numbers		Marked (copied) automatically • at the same positions as the source. • when the recorder is paused while recording.	Marked automatically • after more than 2 seconds of blank or low-level segment. • when the recorder is paused while recording. You can erase unnecessary marks after recording ("Erasing a track mark", page 22).
Recorded sound level		Same as the source	Adjusted automatically. Can also be adjusted manually ("Adjusting the recording level manually", page 13).



Note

Track marks may be copied incorrectly :

- when you record from some CD players or multi disc players using digital input.
- when the source is in shuffle or program play mode while recording using digital input. In this case, play the source in normal play mode.

Recording with digital input

This unit has a built-in sampling rate converter so that you can record programs from digital equipment using other sampling rates, such as a BS tuner or a DAT deck.



- 1 Insert a recordable MD and start recording.
For recording operations, see "Recording an MD right away !" (page 6). To record from a portable CD player, set the CD player to pause and then start recording.

LINE IN (OPTICAL) jack is for both digital and analog input


The recorder automatically recognizes the type of line cable and switches to digital or analog input.

Notes

- You can make a digital recording only from an optical type output.
 - When recording from a portable CD player, play it on AC power and disable the anti-skip function (such as ESP*).
- * Electronic Shock Protection


To start/stop recording in sync with the source player (Synchro-recording)

You can easily make digital recordings of a digital source on an MD. Before synchro-recording, make connections to the digital source with a digital cable, and insert a recordable MD.



SYNCHRO REC

- 1 Slide SYNCHRO REC to ON. "SYNC" appears in the display.



- 2 Press and slide REC to the right. The recorder stands by for recording.
- 3 Play the source sound. The recorder starts recording when it receives the playing sound.

To stop recording, press ■.

continued




- You cannot pause manually during synchro-recording.
- When there is no sound from the player for more than 3 seconds during synchro-recording, the recorder goes into the standby mode automatically. When the sound comes from the player again, the recorder resumes synchro-recording. If the recorder is kept in the standby mode for 5 minutes or longer, the recorder stops automatically.

Notes

- Do not switch SYNCHRO REC after step 2. Recording may not be done properly.
- When recording in monaural, follow steps 1 and 2 of "Recording in monaural for double the normal recording time" (page 13) before synchro-recording.

Recording from a microphone

Connect a stereo microphone (ECM-717, ECM-MS907, ECM-MS957, etc.; not supplied) to the MIC (PLUG IN POWER) jack.




- 1 Select the sensitivity with MIC SENS (at the bottom of the recorder). Usually, set it to HIGH. When recording loud sounds such as a live concert, set it to LOW.
- 2 Insert a recordable MD and start recording. Press and slide REC to the right. "REC" lights up and recording starts. For other operations, see "Recording an MD right away!" (page 6).

Note

To record from a microphone, you must first disconnect any digital source. If connected, the recorder will not switch to microphone input.

Recording in monaural for double the normal recording time

For longer recordings, choose to record in monaural. The recording time becomes double the normal.



- 1 While pressing **||**, press and slide REC to the right. The recorder stands by for recording.
- 2 Press MODE. "Mono REC" appears in the display, and the recorder switches to monaural recording. Press MODE again to record in stereo.
- 3 Press **||** again to start recording.
- 4 Play the sound source.

To stop recording, press ■.


The recorder switches back to stereo recording when you record the next time.

Notes


- If you record a stereo source in monaural, the sounds from left and right will be mixed.
- You cannot record in monaural if SYNCHRO REC is slid to ON.
- The MDs recorded in monaural can be played back only with an MD player/recorder that has the monaural playing function.

Adjusting the recording level manually (Manual recording)

When you record with an analog input, the sound level is adjusted automatically. If necessary, you can set the level manually.




- 1 While holding down **||**, press and hold REC to the right for more than 2 seconds. "ManualREC" appears and the recorder stands by for recording. To return to the automatic control, while the recorder is in standby mode, press and hold REC to the right again for more than 2 seconds.



- 2 Play the source.

continued


- 3** While observing the level meter in the display, adjust the recording level by pressing ►► (+) or ◄◄ (-). Set the level so that it hits the seventh indicator from the bottom at maximum input level.



Note
Adjust the recording level while the recorder is in standby mode. You cannot adjust it while recording.


- 4** Press **||** again to start recording.

To stop recording, press ■.
The recording level control is switched back to automatic control.

 When you record with microphone input, select the sensitivity with MIC SENS (page 12).


Checking the remaining time or the recording position

On the recorder



- 1** Press DISPLAY while recording or in stop mode. Each time you press the button, the display changes as follows.

Position pointer (shows the current location on the MD)



While recording

A	B
Elapsed time	Track number
Remaining time for recording	Track number
Current time ¹⁾	Current date ¹⁾

¹⁾ Appears only when the clock is set.


In stop mode

A	B
Elapsed time	Track number
Remaining time for recording	Track name ¹⁾
Remaining time after the current location	Disc name ¹⁾
Current time ²⁾	Current date ²⁾


¹⁾ Appears only if the track has been labeled.

²⁾ Appears only when the clock is set.

On the remote control



- 1** Press DISPLAY while recording or in stop mode. Each time you press the button, the display changes as follows.



While recording

A	B
Track number	Elapsed time
Track number	Remaining time for recording
—	Current time ¹⁾

¹⁾ Appears only when the clock is set.

In stop mode

A	B
Track number	Elapsed time
Track number	Track name ¹⁾
Number of tracks in the disc	Disc name ¹⁾
—	Current time ²⁾


¹⁾ Appears only if the track has been labeled.

²⁾ Appears only when the clock is set.

To know the recording condition


The REC indicator lights up or flashes according to the recording condition.

Recording condition	REC indicator
While recording	lights up flashes according to the loudness of the source while recording with a microphone (voice mirror)
Recording standby	flashes
Less than 3 minutes' recording time available	flashes slowly
A track mark has been added	goes off momentarily

 If you want to check the playing position or track name while playing, see page 19.


Setting the clock to stamp the recorded time

To stamp the date and time on the MD when you record, you first need to set the clock.



CLOCK SET
(at the bottom)

- 1 Connect the power source. Use the supplied AC power adaptor.
- 2 Press CLOCK SET at the bottom of the recorder. Use a pointed object. The digits of the year flash.



- 3 Change the current year by pressing ◀◀ or ▶▶. To change the digits rapidly, keep pressing ◀◀ or ▶▶.

- 4 Press ▶ to enter the year. The digit of the month flashes.
- 5 Repeat steps 3 and 4 to enter the current month, date, hour, and minute. When you press ▶ to enter the minute, the clock starts operating.

If you make a mistake while setting the clock

Press ■, and set the clock again from step 2. You can skip a step by pressing ▶.

To display the current time

When the recorder is not operating or while recording, press DISPLAY repeatedly until the current time appears in the display.

To display the time in the 24-hour system

While setting the clock, press DISPLAY. To display the time in the 12-hour system, press DISPLAY again.


Charging the built-in battery for the clock

When you use the recorder for the first time or after a long period of disuse, charge the built-in battery. After setting the clock, leave the recorder connected to the AC power for about 2 hours to charge the built-in battery. Once charged, the built-in battery should last about a month without connecting to any of the power sources. The recorder will automatically charge the built-in battery while connected to AC power, dry batteries or a rechargeable battery.

► Various ways of playback

Selecting the track number or track name directly

You can select the desired track directly by using the vertical jog dial.



- 1 Rotate the jog dial to select a track, and press it to play the selected track.



Rotate to select.

Press to play.

When you rotate the jog dial, the track name* appears in the display. To play the selected track, press the jog dial.


* If the track has not been labeled, only the track number appears in the display.



If you select a track in shuffle play mode, shuffle play starts from the selected track.


Playing tracks repeatedly

You can play tracks repeatedly in three ways — all repeat, single repeat, and shuffle repeat.



- 1 Press MODE (PLAY MODE on the remote control) while the recorder is playing an MD. Each time you press the button, the play mode indication changes as follows.

Ex: Display on the main unit




Play mode indication

Indication	Play mode
none (normal play)	All the tracks are played once.
"◁"	All the tracks are played repeatedly.
"◁ 1"	A single track is played repeatedly.
"◁ SHUF"	All the tracks are played repeatedly in random order.

Emphasizing bass (DIGITAL MEGA BASS)


Mega Bass function intensifies low frequency sound for richer quality audio reproduction. It affects only the sound from the headphones.





DIGITAL MEGA BASS

- 1 Press DIGITAL MEGA BASS. Each time you press DIGITAL MEGA BASS, the Mega Bass indication changes as follows.

Mega Bass indication




Indication	Play mode
none	Normal play
"BASS  "	Mega Bass (moderate effect)
"BASS  "	Mega Bass (strong effect)

Notes

- If the sound becomes distorted when emphasizing bass, turn down the volume.
- Mega Bass function does not affect the sound being recorded.
- Mega Bass does not function when a line cable is connected to the LINE OUT jack on the recorder.

Protecting your hearing (AVLS)


The AVLS (Automatic Volume Limiter System) function keeps down the maximum volume to protect your ears.



- 1 Set AVLS at the bottom of the recorder to LIMIT. When you try to turn the volume too high, "AVLS" appears in the display. The volume is kept to a moderate level.


Checking the remaining time or the playing position

On the recorder



- 1 Press DISPLAY while playing. Each time you press DISPLAY, the display changes as follows.

Position pointer (shows the current location on the MD)




A	B
Elapsed time	Track number
Remaining time of the current track	Track name ¹⁾
Remaining time after the current location	Disc name ¹⁾
Recorded time ²⁾	Recorded date ²⁾


¹⁾Appears only if the track has been labeled.

²⁾Appears only when the clock is set.

On the remote control



- 1 Press DISPLAY while playing. Each time you press DISPLAY, the display changes as follows.



A	B
Track number	Elapsed time
Track number	Track name ¹⁾
The number of tracks in the disc	Disc name ¹⁾
—	Recorded time ²⁾

¹⁾Appears only if the track has been labeled.


²⁾Appears only when the clock is set.



If you want to check the remaining time or the recording position while recording or in stop mode, see page 14.

Locking the controls (HOLD)

To prevent the buttons from being accidentally operated when you carry the recorder, use this function.




- 1 Slide HOLD in the direction of the arrow.

On the recorder, slide HOLD to lock the controls of the recorder. On the remote control, slide HOLD to lock the controls of the remote control.

Slide HOLD in the opposite direction of the arrow to unlock the controls.

Connecting to a stereo system

Connect the LINE OUT jack of the recorder to the LINE IN jacks of an amplifier or a tape player with a line cable (RK-G129 or RK-G136, not supplied). The output is analog. The recorder plays the MD digitally and sends analog signals to the connected equipment.



Note
The Mega Bass does not function or will be cancelled when the LINE OUT jack is connected with a line cable.

▶Editing recorded tracks

You can edit your recordings by adding/erasing track marks or labeling tracks and MDs. Premastered MDs cannot be edited.

Notes on editing


- Do not move or jog the recorder while "Toc Edit" is flashing in the display.
- You cannot edit tracks on an MD that is record-protected. Before editing tracks, close the tab on the side of the MD.

*TOC = Table of Contents

Erasing tracks

To erase a track

Note that once a recording has been erased, you cannot retrieve it. Make sure of the track you are erasing.



- 1 Press ERASE while playing the track you want to erase. "Erase OK?" and "Push Erase" appear in the display alternately, and the recorder plays the selected track repeatedly. To cancel erasing, press ■.
- 2 Check the track number in the display and press ERASE again. The track is erased from the MD and the remaining tracks are renumbered.


To erase a part of a track

Add track marks at the beginning and the end of the part you want to erase, then erase the part.

To erase the whole disc

You can quickly erase all the tracks and data of the MD at the same time.

Note that once a recording has been erased, you cannot retrieve it. Be sure to check the contents of the disc you want to erase.





- 1 In stop mode, keep pressing ERASE and press and slide REC to the right. "All Erase?" and "Push Erase" appear in the display alternately. To cancel erasing, press ■.
- 2 Press ERASE again. "Toc Edit" flashes in the display. When erasing finishes, "BLANK DISC" appears.

Adding a track mark

You can add track marks so that the part after the new track mark is counted as a new track.

The track numbers will increase as follows.



- 1 While playing or pausing an MD, press T MARK on the recorder at the point you want to mark. "MARK ON" appears in the display, and a track mark is added. The track number will increase by one.

To add track marks while recording



Press T MARK on the recorder or TRACK MARK on the remote control.

Note

TRACK MARK on the remote control does not function during playback.

Erasing a track mark

When you record with analog (line) input, unnecessary track marks may be recorded where recording level is low. You can erase a track mark to combine the tracks before and after the track mark. The track numbers will change as follows.



- 1 While playing the track with the track mark you want to erase, press **||** to pause.
- 2 Find the track mark by pressing **◀◀** slightly. For example, to erase the third track mark, find the beginning of the third track. "00:00" appears in the display.
- 3 Press T MARK to erase the mark. "MARK OFF" appears in the display. The track mark is erased and the two tracks are combined.




When you erase a track mark, the date, time, and name assigned to the mark are also erased.


Moving recorded tracks

You can change the order of the recorded tracks.


Before moving



After moving



Move track C from the third to the second track.




- 1 While playing the track you want to move, keep pressing **▶** and press TITILE/ENTER. The recorder plays the selected track repeatedly. For the example above, "MV003→003" appears in the display.
- 2 Rotate the vertical jog dial to select the new track position. For the example above, rotate the jog dial until "MV003→002" appears in the display. To cancel moving, press **■**.
- 3 Press TITILE/ENTER again. Moving is completed and the recorder plays the moved track.



You can also move the track by pressing the jog dial in step 3.

Labeling recordings


You can label the MDs and tracks you recorded with letters, numbers, and marks. Each label can be made up of up to 200 characters, and each MD can hold up to 1700 characters.



- 1 To label a track, play the track you want to label. To label an MD, insert the recordable MD you want to label. If an MD is already inserted, press **■** to stop.
- 2 Press TITILE/ENTER. If you have selected a track in step 1 above, the recorder will play that track repeatedly. A cursor flashes in the display.
- 3 Use the vertical jog dial to select and enter a character.



Rotate to select.



Press to enter.

Rotate the jog dial to select a character, and press the jog dial to enter the selected character. The cursor shifts rightward and stands by for the input of the next character.

continued

Press	To
▶	Switch between capital letters, small letters, and marks/numbers.
◀◀/▶▶	Move the cursor to the left or right.
END SEARCH	Insert a space.
ERASE	Delete a character.
■	Cancel labeling.

4 Repeat step 3 until you have entered all the characters for the label.

5 Press TITLE/ENTER.
Labeling is completed.

To cancel labeling, press ■.

Available characters

- Capital and small letters of the English alphabet
- Numbers 0 to 9
- ! " # \$ % & () * + - . ; < = > ?
@ _ ` ' , / : _ (space)

To relabel recordings

Follow steps 1 and 2 to display the label of the track or MD. Enter a new character over the one you want to change, then press TITLE/ENTER.

Notes

- You cannot relabel premastered MDs or label MDs that have not been recorded.
- The recorder is able to display, but cannot label using Japanese "Katakana" characters.

►Power sources

You can use the recorder on house current or as follows.

In the recorder ...

- a lithium ion rechargeable battery (supplied)

With supplied battery case ...


- dry batteries (not supplied)

It is preferable to use the recorder on house current when recording for a long time.



Using a lithium ion rechargeable battery

Before using the supplied LIP-8 lithium ion rechargeable battery for the first time, charge it in the recorder.

- 1 Connect the supplied AC power adaptor.



- 2 Insert the LIP-8 into the recorder and close the lid.



Battery indication appears in the display and charging starts. When charging is completed, battery indication disappears.

Charging time

80%	Approx. 2 hours
-----	-----------------

100%	Approx. 3 hours
------	-----------------

(To charge a completely discharged battery)




You can use the recorder while charging.

Notes


- Be sure to use the supplied AC power adaptor.
- Charging time may vary depending on the battery condition.

Using dry batteries

- 1 Attach the supplied battery case.



- 2 Insert two LR6 (size AA) dry batteries (not supplied).



Battery life¹⁾


Batteries	Recording ²⁾	Playback
LIP-8 lithium ion rechargeable battery	Approx. 4 hours	Approx. 7 hours
Two LR6 (size AA) Sony alkaline dry batteries	----- ³⁾	Approx. 12 hours
LIP-8 + Two LR6 (size AA)	----- ³⁾	Approx. 22 hours

¹⁾The battery life may be shorter due to operating conditions and the temperature of the location.

²⁾When you record, use a fully charged rechargeable battery.

³⁾Recording time may differ according to the alkaline batteries.

When to replace the batteries

When the dry batteries or rechargeable battery are weak, flashing  or "LOW BATT" appear in the display. Replace the dry batteries or charge the rechargeable battery.

►Additional information

Precautions

On safety

Do not put any foreign objects in the DC IN 6 V jack.

On power sources

- Use house current, lithium ion rechargeable battery, two LR6 (size AA) batteries, or car battery.
- For use in your house: Use the AC power adaptor supplied with this recorder. Do not use any other AC power adaptor since it may cause the recorder to malfunction.

Polarity of the plug



- The recorder is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the recorder itself has been turned off.
- If you are not going to use this recorder for a long time, be sure to disconnect the power supply (AC power adaptor, dry batteries, rechargeable battery, or car battery cord). To remove the AC power adaptor from the wall outlet, grasp the adaptor plug itself; never pull the cord.
- For use in the car: Use the CPA-8 or CPA-9 car connecting pack and the DCC-E260 car battery cord (not supplied).

On heat build-up

Heat may build up in the recorder if it is used for an extended period of time. In this case, leave the recorder turned off until it cools down.

On installation

- Never use the recorder where it will be subjected to extremes of light, temperature, moisture or vibration.
- Never wrap the recorder in anything when it is being used with the AC power adaptor. Heat build-up in the recorder may cause malfunction or damage.

On the headphones

Road safety

Do not use headphones while driving, cycling, or operating any motorized vehicle. It may create a traffic hazard and is illegal in many areas. It can also be potentially dangerous to play your recorder at high volume while walking, especially at pedestrian crossings. You should exercise extreme caution or discontinue use in potentially hazardous situations.

Preventing hearing damage

Avoid using headphones at high volume. Hearing experts advise against continuous, loud and extended play. If you experience a ringing in your ears, reduce the volume or discontinue use.

Caring for others

Keep the volume at a moderate level. This will allow you to hear outside sounds and to be considerate of the people around you.

On the MiniDisc cartridge

- Do not break open the shutter.
- Do not place the cartridge where it will be subject to light, extreme temperatures, moisture or dust.

On cleaning

- Clean the recorder casing with a soft cloth slightly moistened with water or a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene as it may mar the finish of the casing.
- Wipe the disc cartridge with a dry cloth to remove dirt.
- Dust on the lens may prevent the unit from operating properly. Be sure to close the disc compartment lid after inserting or ejecting an MD.

Notes on batteries

Incorrect battery usage may lead to leakage of battery fluid or bursting batteries. To prevent such accidents, observe the following precautions:

- Install the + and – poles of the batteries correctly.
- Do not install new and used batteries or different kinds of batteries together.
- Do not try to recharge dry batteries.
- When the recorder is not to be used for a long time, be sure to remove the batteries.
- If a battery leak should develop, carefully and thoroughly wipe away battery fluid from the battery compartment before inserting new ones.


Note on mechanical noise

The recorder gives off mechanical noise while operating, which is caused by the power-saving system of the recorder and it is not a problem.

To protect a recorded MD


To record-protect an MD, slide open the tab at the side of the MD. In this position, the MD cannot be recorded. To record again, slide the tab back so the tab is visible.

Back of the MD



Note on digital recording

This recorder uses the Serial Copy Management System, which allows only first-generation digital copies to be made from mastered software. You can only make copies from a home-recorded MD by using the analog (line out) connections.



If you have any questions or problems concerning your recorder, please consult your nearest Sony dealer.

Troubleshooting

Should any problem persist after you have made these checks, consult your nearest Sony dealer.

Symptom

Cause/Solution

The recorder does not work or works poorly.

- Audio sources may not be securely connected.
 - ➔ Disconnect the audio sources once and connect them again (pages 6,11).
- Moisture has condensed inside the recorder.
 - ➔ Take the MD out and leave the recorder in a warm place for several hours until the moisture evaporates.
- The rechargeable battery or dry batteries are weak (□ or "LOW BATT" flashes).
 - ➔ Charge the rechargeable battery or replace the dry batteries (pages 25, 26).
- The rechargeable battery or dry batteries have been installed incorrectly.
 - ➔ Install the batteries correctly (page 26).
- You pressed a button while the disc indication was rotating quickly.
 - ➔ Wait until the indication rotates slowly.
- The recording volume is too low.
- When recording digitally from a portable CD player, you did not use AC power or did not disable the anti-skip function such as ESP (page 11).
- The analog recording was made using a connecting cord with an attenuator.
 - ➔ Use a connecting cord without an attenuator (page 6).
- The AC adaptor was unplugged during recording or a power outage occurred.
- While operating, the recorder received a mechanical shock, too much static, abnormal power voltage caused by lightning, etc.
 - ➔ Restart the operation as follows.
 - 1 Disconnect all the power sources.
 - 2 Leave the recorder for about 30 seconds.
 - 3 Connect the power source.

No sound comes through the headphones.

- The headphones plug is not firmly connected.
 - ➔ Plug in the plug of the headphones firmly to the remote control. Plug in the plug of the remote control firmly to Ⓜ/REMOTE.
- Volume is too low.
 - ➔ Adjust the volume by pressing VOLUME +/- (VOL +/- on the remote controller).
- AVLS is on.
 - ➔ Slide AVLS to NORMAL (page 18).

Symptom	Cause/Solution
An MD is not played from the first track.	<ul style="list-style-type: none"> • Disc playing stopped before it came to the last track. <ul style="list-style-type: none"> ➔ Press ◀◀ repeatedly or open and close the lid once to go back to the beginning of the disc, and restart playing after checking the track number in the display.
Playback sound skips.	<ul style="list-style-type: none"> • The recorder is placed where it receives continuous vibration. <ul style="list-style-type: none"> ➔ Put the recorder on a stable place. • A very short track may cause sound to skip.
Sound has a lot of static.	<ul style="list-style-type: none"> • Strong magnetism from a television or such device is interfering with operation. <ul style="list-style-type: none"> ➔ Move the recorder away from the source of strong magnetism.
Cannot find the track marks.	<ul style="list-style-type: none"> • You pressed after pressing ◀◀ or ▶▶. ➔ Press before pressing ◀◀ or ▶▶.
Charging the rechargeable battery does not start.	<ul style="list-style-type: none"> • The rechargeable battery has been inserted incorrectly or the AC power adaptor has been connected incorrectly. <ul style="list-style-type: none"> ➔ Insert the battery correctly or connect the AC power adaptor correctly.
The clock loses time or the display flashes. The recording date was not stamped onto the disc.	<ul style="list-style-type: none"> • The built-in battery for the clock is weak. <ul style="list-style-type: none"> ➔ Connect the AC power adaptor to DC IN 6 V on the recorder and the wall outlet to charge the built-in battery. After charging, set the clock again (page 16). Note that the clock normally loses about 2 minutes per month.

System limitations

The recording system in your MiniDisc recorder is radically different from those used in cassette and DAT decks and is characterized by the limitations described below. Note, however, that these limitations are due to the inherent nature of the MD recording system itself and not to mechanical causes.

Symptom	Cause
"TR FULL" appears even before the disc has reached the maximum recording time (60 or 74 minutes).	When 254 tracks have been recorded on the disc, "TR FULL" appears regardless of the total recorded time. More than 254 tracks cannot be recorded on the disc. To continue recording, erase unnecessary tracks.
"TR FULL" appears even before the disc has reached the maximum track number or recording time.	Repeated recording and erasing may cause fragmentation and scattering of data. Although those scattered data can be read, each fragment is counted as a track. In this case, the number of tracks may reach 254 and further recording is not possible. To continue recording, erase unnecessary tracks.
Track marks cannot be erased.	When the data of a track is fragmented, the track mark of a fragment under 12 seconds long cannot be erased. You cannot combine a track recorded in stereo and a track recorded in monaural; nor can you combine a track recorded with digital connection and a track recorded with analog connection.
The remaining recording time does not increase even after erasing numerous short tracks.	Tracks of under 12 seconds in length are not counted and so erasing them may not lead to an increase in the recording time.
The total recorded time and the remaining time on the disc may not total the maximum recording time (60 or 74 minutes).	Recording is done in minimum units of 2 seconds each, no matter how short the material. Even if the last unit of recording is less than 2 seconds, it is counted as a unit of 2 seconds. Then 2 seconds' space is put before recording starts again to prevent the last unit of the previous track from being erased. The contents recorded may thus be shorter than the maximum recording capacity.
The edited tracks may exhibit sound dropout during search operations.	The fragmentation of data may cause sound dropout while searching because the tracks are played in higher speed than normal playback.

Messages


If the following error messages flash in the display window, check the chart below.

Error message	Meaning/Remedy
BLANK DISC	<ul style="list-style-type: none"> An MD with no recording on it is inserted. ➔ Insert a recorded MD.
DISC ERR	<ul style="list-style-type: none"> The recorder cannot read the disc (it's scratched or dirty). ➔ Reinsert or replace the disc.
DISC FULL	<ul style="list-style-type: none"> There is no more space to record on the disc (less than 12 seconds available). ➔ Replace the disc.
Data Save	<ul style="list-style-type: none"> The MD player is recording information (sounds) from the memory to the disk. ➔ Wait until this process is completed. Do not expose the player to any physical shock, nor disrupt power supply.
Toc Edit	<ul style="list-style-type: none"> The MD player is recording information (track start and end position) from the memory to the disk. ➔ Wait until this process is completed. Do not expose the player to physical shock, nor disrupt power supply.
BUSY	<ul style="list-style-type: none"> You tried to operate the recorder while it was accessing the recorded data. ➔ Wait until the message goes out (in rare cases, it may take 2-3 minutes).
NAME FULL	<ul style="list-style-type: none"> You tried to enter more than 200 characters for a track or disc name or the total characters entered in an MD is more than 1700. ➔ Enter the characters within the limit.
Hi DC in	<ul style="list-style-type: none"> Voltage of the power supply is too high (The supplied AC power adaptor or the recommended car battery cord is not used). ➔ Use the supplied AC power adaptor or the recommended car battery cord.
HOLD	<ul style="list-style-type: none"> The recorder is locked. ➔ Slide HOLD against the arrow to unlock the recorder (page 20).
LOW BATT	<ul style="list-style-type: none"> Batteries are weak. ➔ Charge the rechargeable battery or replace the dry batteries (pages 25, 26).
MEM OVER	<ul style="list-style-type: none"> You tried to record when there is no indication in the display, with the recorder placed where it receives continuous vibration. ➔ Put the recorder on a stable place, and start recording again.

Error message	Meaning/Remedy
NO COPY	<ul style="list-style-type: none"> You tried to make a copy from a disc that is protected by the Serial Copy Management System. You cannot make copies from a digitally connected source which was itself recorded using digital connection. ➔ Use analog connection instead (page 6).
NO DISC	<ul style="list-style-type: none"> You tried to play or record with no disc in the recorder. ➔ Insert an MD.
NO SIGNAL	<ul style="list-style-type: none"> The recorder could not detect digital input signals. ➔ Make sure that the source is connected firmly (page 11). • If the error message appears while recording, press ■ to stop recording.
P/B ONLY	<ul style="list-style-type: none"> You tried to record or edit on a premastered MD (P/B means playback.) ➔ Insert a recordable MD.
PROTECTED	<ul style="list-style-type: none"> You tried to record or edit on a MD with the tab in the record-protect position. ➔ Slide the tab back (page 28).
SORRY	<ul style="list-style-type: none"> You tried to erase a track mark while playing the MD or at the beginning of the first track. You tried to erase a track mark to combine tracks the recorder cannot combine (caused by system limitation).
TEMP OVER	<ul style="list-style-type: none"> Heat has built up in the recorder. ➔ Let the recorder cool down.
TR FULL	<ul style="list-style-type: none"> There is no more space for new data when you are editing the MD. ➔ Erase unnecessary tracks (page 21).
TrPROTECT	<ul style="list-style-type: none"> You tried to record or edit on a track that is protected from erasing. ➔ Record or edit on other tracks.


SECTION 3 DISASSEMBLY

- The equipment can be removed using the following procedure.




Note : Follow the disassembly procedure in the numerical order given.


3-1. UPPER PANEL ASSY, BOTTOM PANEL ASSY REMOVAL




3-2. MAIN BOARD REMOVAL




3-3. MECHANISM DECK (MT-MZR50-143) REMOVAL




3-4. OPTICAL PICK-UP ASSY, REC BOARD REMOVAL




3-5. CLV BOARD REMOVAL




3-6. BATTERY CASE ASSY REMOVAL



3-7. POWER BOARD, SWITCH BOARD REMOVAL



3-8. SWITCH UNIT (WITH JOG DIAL) REMOVAL



SECTION 4 TEST MODE


[Outline]

- The general adjustment mode of this unit performs CD and MO adjustments automatically when set. In this mode, the disc is determined if CD or MO and adjustments are automatically performed in order. If errors are detected, the faulty locations are displayed. The servo mode performs each adjustment automatically.

[Setting the Test Mode]

Short-circuit the soldering bridge of TAP803 (TEST) on the main board (connect Pin ②⑥ of IC801 to the GND) and turn on the power supply.

[MAIN BOARD] (SIDE B)




[Exiting the Test Mode]

Turn off the power supply and open the soldering bridge of TAP803 (TEST) on the main board.

[Operations When Test Mode is Set]


When the test mode is set, the LCD will display as follows.



- The LCD performs the following repeatedly.
ROM version displayed → all lit → all off
- The display can be held and checked by pressing **||** key.
- The self-diagnostic display appears while the DISPLAY key is pressed.

[Structure of Test Mode]

The test mode of this unit consists of the following five modes.






- In modes other than the general adjustment mode, the last two digits of the mode number will be displayed at the **00** section.

[Servo Mode]

- Set the test mode, press the ►►► key, and set the servo mode using the VOLUME + and – keys.
- When the servo mode is set, the optical pickup will move to the outer circumference or inner circumference if the ►►► key or ◀◀◀ key is pressed.
- To set other modes, refer to “Structure of Test Mode”.

• Structure of Servo Mode







• Adjusting Method

Note : There is basically no display for individual adjustment items. Only such upper position titles as SERVO, AUDIO, etc. (100s position) are displayed.

1. When the adjustment modes are set according to “Structure of Servo Mode”, the last two digits of the mode number and the adjustment value written in the EEPROM will be displayed blinking.




2. When the ■ key is pressed, the following will be displayed and adjustments will be performed automatically.




Note : The adjustment value can be changed as desired using the VOLUME + and - keys, but try to avoid this as much as possible.

3. After the adjustments are completed, the item is displayed again and the adjustment value that was blinking lights up.



• Cluster Display





- Nothing is performed at mode numbers 070 to 073.

[Audio Mode]


- Set the test mode, press the ►► key, and set the audio mode using the VOLUME + and – keys.
- To set other modes, refer to “Structure of Test Mode”.

• Structuer of Audio Mode



(To page 29)

(To page 29)




- When the ■ key is pressed at mode numbers 100, 110 to 114, the buzzer will sound.
- When the VOLUME keys + and – are pressed at mode numbers 111 to 113, 123, 124, the volume of the headphone output will increase/decrease.
When the ◀◀ key or ▶▶ key is pressed, the volume of the headphone output will become maximum/minimum.
- When the VOLUME keys + and – are pressed at mode numbers 121 or 122, the recording level will increase/decrease.
When the ◀◀ key or ▶▶ key is pressed, the recording level will become maximum/minimum.
- The record LED lights up in mode numbers 121 to 124 and are off at mode numbers 110 to 114.
- At mode numbers 121 to 124, the microprocessor will detect the port and automatically determine the input.
- The following indicators light up with the deck sensor switches at ON.
At REFLECT switch ON : the “↶” indicator lights up
At MEDIA switch ON : the “SHUF” indicator lights up
At PROTECT switch ON : the “1” indicator lights up

[Mecha Mode]

- Set the test mode, press the ▶▶ key, and set the mecha mode using the VOLUME + and – keys.
- To set other modes, refer to “Structure of Test Mode”.

• Structure of Mecha Mode




- At mode numbers 200, 210 to 212, the optical pick up can be moved to the outer circumference or inner circumference using the ◀◀ or ▶▶ key.

[Power supply Mode]


- Set the test mode, press the + key, and set the power supply mode using the VOLUME + and – keys.
- To set other modes, refer to “Structure of Test Mode”.

• Structure of Power Supply Mode




[General Adjustment Mode]

- Set the test mode, press the ►► key, and set the general adjustment mode.
- To set other modes, cut off the power once and power on again.
- When the general adjustment mode is set, the LCD display will be as follows.



• Structure of General Adjustment Mode




Adjusting Method :

1. Set the test mode, press the ◀◀ key to set the general adjustment mode.
2. Load the CD test disc (TDYS-1) or SONY MO disc available on the market.
3. When the ► key is pressed, the disc is determined if CD or MO, the automatic adjustment modes are set, and adjustments are performed automatically in the following order.

• CD Automatic Adjustment

No.	Mode No.	Adjustment
1	052	CD EF balance adjustment
2	053	CD ABCD level adjustment
3	055	CD focus gain adjustment
4	056	CD tracking gain adjustment
5	057	CD focus bias adjustment


* Display during CD automatic adjustment




• MO Automatic Adjustment

No.	Mode No.	Adjustment
1	032	MO playback EF balance adjustment
2	033	MO playback ABCD level adjustment
3	034	MO recording EF balance adjustment
4	035	MO recording ABCD level adjustment
5	037	MO focus gain adjustment
6	038	MO tracking gain adjustment
7	061	32 cluster full REC
8	062	REC shock
9	063	32 cluster PLAY
10	039	MO focus bias adjustment
11	042	Low reflection CD EF balance adjustment
12	043	Low reflection CD ABCD level adjustment
13	045	Laser low reflection CD read adjustment
14	046	Low reflection CD tracking gain adjustment


* Display during MO automatic adjustment




4. If the automatic adjustment results are OK, the following will be displayed.




5. If the automatic adjustment results are NG, the following will be displayed.



* When the mode number is 039, 057 and the focus bias value is NG, the following will be displayed



* When the mode number is 039, 061 and the AT error rate is NG, the following will be displayed.



* When NG, set the servo mode and perform the automatic adjustment of the NG item. (Refer to "Servo Mode").


SECTION 5 ADJUSTMENTS

5-1. Precautions for Laser Diode Emission Check

When checking the emission of the laser diode during adjustments, never view directly downwards as this may lead to blindness.

5-2. Precautions for Using Optical Pickup (KMS-280A)

As the laser diode inside the optical pickup damages by static electricity easily, solder the laser tap of the flexible board when handling. Also take the necessary measures to prevent damages by static electricity. Handle the flexible board with care as it breaks easily




Optical Pickup flexible board

5-3. Precautions for Adjustment

- 1) Perform all adjustments in the order given in the test mode.
After adjusting, exit the test mode.
- 2) Use the following tools and measuring instruments.
 - CD test disc TDYS-1
(Parts Code : 4-963-646-01)
 - Recorded MO disc PTDM-1
(Parts Code : J-2501-054-A)
 - Laser power meter LPM-1
(Parts Code : J-2501-046-A)
 - Oscilloscope (Frequency band above 40MHz. Perform the calibration of probe first before measuring.)
 - Digital voltmeter
- 3) Unless specified otherwise, supply DC 6V from the DC IN 6V jack.
- 4) Swtich, knob positions
 Hold switch OFF
 AVLS switch NORM

5-4. DD 2.8V Adjustment

Connection :




Adjusting Method :


1. Connect the digital voltmeter to test point TP8507 (+2.8V) and TP8505 (AGND) on power board.
2. Adjust the RV801 for 2.8V reading on the digital voltmeter.

Connection point and adjustment location : POWER board

**[POWER BOARD]
(SIDE A)**




**[POWER BOARD]
(SIDE B)**



5-5. Laser Power Check

Connection :




Adjusting Method :

1. Set the servo mode of the test mode (Mode : 000).
2. Press the ► key, and set the laser power adjustment mode (Mode : 020) using the volume + and – keys.
3. Press the ◀◀ key and move the optical pickup to the inner most circumference.
4. Open the cover and set the laser power meter on the objective lens of the optical pickup.
5. Press the ► key, and set the laser MO read adjustment mode (Mode : 021).
6. Check that the laser power meter reading is $0.85 \pm 0.085\text{mW}$.
7. Check that the voltage between AP574 (LDIO) and AP5117 (VCC) at this time is below 44mV.
8. Press the ► key, and set the laser MO write adjustment mode (Mode : 022).
9. Check that the laser power meter reading is $6.8 \pm 0.68\text{mW}$.
10. Press the ■ key to finalize the adjustment data.
11. Check that the voltage between AP574 (LDIO) and AP5117 (VCC) at this time is below 80mV.
12. Press the ■ key.
13. Exit the test mode.

5-6. MO Traverse Adjustment


Connection :



Adjusting Method :

1. Set the servo mode of the test mode (Mode : 000).
2. Press the ► key, and set the MO playback adjustment mode (Mode : 030) using the volume + and – keys.
3. Press the ◀◀ and ▶▶ keys and move the optical pickup to the center circumference.
4. Load any MO disc available on the market.
5. When the ► key is pressed, the MO playback EF balance adjustment mode (Mode : 032) will be set after focus search ON (Mode : 031).
6. Press the ■ key to perform automatic adjustment, and check that the traverse waveform is symmetrical at the top and bottom.
7. Slide the recording key and set the MO recording EF balance adjustment mode (Mode : 034).
8. Press the ■ key to perform automatic adjustment, and check that the traverse waveform is symmetrical at the top and bottom.

(Traverse Waveform)




Specification : $A = B$, $C \geq 1.0 \text{ Vp-p}$

9. Check that the traverse level at this time is above 1.0Vp-p.
10. Press the ■ key.
11. Exit the test mode.

Note : Using a recorded disc in this adjustment will erase the data.


5-7. Low Reflection CD Traverse Adjustment

Connection :



Adjusting Method :

1. Set the servo mode of the test mode (Mode : 000).
2. Press the ► key, and set the low reflection CD playback adjustment mode (Mode : 040) using the volume + and – keys.
3. Load any MO disc available on the market.
4. When the ► key is pressed, the low reflection CD playback EF balance adjustment mode (Mode : 042) will be set after low reflection CD focus search ON (Mode : 041).
5. Press the ■ key to perform automatic adjustment, and check that the traverse waveform is symmetrical at the top and bottom. (*Traverse Waveform*)




Specification : $A = B, C \geq 0.9V_{p-p}$

6. Check that the traverse level at this time is above $0.9V_{p-p}$.
7. Press the ■ key.
8. Exit the test mode.

5-8. CD Traverse Adjustment

Connection :



Adjusting Method :

1. Set the servo mode of the test mode (Mode : 000).
2. Press the ► key, and set the CD playback adjustment mode (Mode : 050) using the volume + and – keys.
3. Press the ◀◀ and ▶▶ keys and move the optical pickup to the center circumference.
4. Load a CD test disc (TDYS-1).
5. When the ► key is pressed, the CD playback EF balance adjustment mode (Mode : 052) will be set after CD focus search ON (Mode : 051).
6. Press the ■ key to perform automatic adjustment, and check that the traverse waveform is symmetrical at the top and bottom.

(*Traverse Waveform*)




Specification : $A = B, C \geq 1.0 V_{p-p}$

7. Check that the traverse level at this time is above $1.0V_{p-p}$.
8. Press the ■ key.
9. Exit the test mode.

5-9. CD RF Level Check


Connection :



Adjusting Method :

1. Set the servo mode of the test mode (Mode : 000).
2. Press the ► key, and set the CD playback adjustment mode (Mode : 050) using the volume + and - keys.
3. Press the ◀◀ and ▶▶ keys and move the optical pickup to the center circumference.
4. Load a CD test disc (TDYS-1).
5. When the ► key is pressed, the CD EF balance adjustment mode (Mode : 052) will be set after CD focus search ON (Mode : 051).
6. When the ► key is pressed, the ABCD level adjustment mode (Mode : 053) is set.
7. Press the ■ key to perform automatic adjustment, and check that the RF level is $1.1 \pm 0.3V_{p-p}$.


(*RF waveform*)




8. Check that the voltage between AP574 (LDIO) and AP5117 (VCC) and at this time is below 40mV.
9. Press the ■ key.
10. Exit the test mode.

Adjustment Location :

[MAIN BOARD] (SIDE B)



[MAIN BOARD] (SIDE A)



SECTION 6 DIAGRAMS

6-1. EXPLANATION OF IC TERMINALS

IC503 DIGITAL SERVO, ATRAC (CXD2652AR)


Pin No.	Pin name	I/O	Description
1	MNT 0	O	Traverse count signal output.
2	MNT 1	O	Track jump detect output.
3	MNT 2	–	Not used (Open).
4	MNT 3	–	Not used (Open).
5	SWDT	I	Inputs write data signal from system controller (IC801).
6	SCLK	I	Inputs serial clock signal from system controller (IC801).
7	XLAT	I	Inputs serial latch signal from system controller (IC801).
8	SRDT	O	Outputs write data signal to system controller (IC801).
9	SENS	O	Outputs internal status (SENSE) to system controller (IC801).
10	XRST	I	Inputs reset signal from system controller (IC801). Reset : L
11	SQSY	O	Output subcode Q sync (SCOR) to system controller (IC801). Outputs “L” every 13.3msec. Outputs “H” at all most mostly.
12	DQSY	O	Outputs digital-in U-bit CD format subcode Q sync (SCOR) to system controller (IC801). Outputs “L” every 13.3msec. Outputs “H” at all most mostly.
13	WRPWR	I	Inputs laser power switching signal from system controller (IC801).
14	NC	–	Not used (Open).
15	TX	I	Input of write data taransmission timing from system controller (IC801). Also used as magnetic field head ON/OFF output.
16	OSC1	O	Clock output (22.5MHz).
17	OSC0	I	Clock input (22.5MHz).
18	XTSL	–	Not used (Fixed at “L”)
19	NC	–	Not used (Ground).
20	RV _{SS}	–	Connect to ground.
21	DIN	I	Digital audio signal input pin (For optical input).
22	NC	–	Not used (Open).
23	ADDT	I	Audio data input from A/D converter (IC303).
24	DATA	O	Monitor/decode audio data output to A/D converter (IC303).
25	ALRCK	O	L/R clock output to D/A converter (IC303).
26	ABCK	O	Bit clock signal output to A/D, D/A converter (IC303).
27	FS256	O	11.2896MHz clock output (MCLK).
28	DV _{DD}	–	Power supply (+2.8V) for digital.
29 – 39	A00 – A08, A10, A11	O	Address signal output to RAM (IC509).
40	DV _{SS}	–	Ground terminal.
41	XOE	O	Output enable contol signal output to RAM (IC509).
42	XCAS	O	Column address strobe singal output to RAM (IC509).
43	A09	O	Address signal output to RAM (IC509).
44	XRAS	O	Row address strobe signal output to RAM (IC509).
45	XWE	O	Read/write control signal output to RAM (IC509).
46 – 49	D0 – D3	I	Data signal input from RAM (IC509).
50	MVCI	–	Not used (Connect to ground).
51	ASYO	O	Playback EFM full-swing output (L : VSS, H : VDD).
52	ASYI	I	Playback EFM asymmetry comparate voltage input.
53	AV _{DD}	–	Power supply (+2.8V) for analog.
54	BIAS	I	Playback EFM asymmetry circuit constant current input.
55	RFI	I	Inputs playback EFM RF signal from RF amplifier (IC501).

Pin No.	Pin name	I/O	Description
56	AV _{SS}	–	Ground terminal.
57	PDO	–	Not used (Open).
58	PCO	O	Decoder PLL master clock PLL phase comparison output.
59	FILI	I	Decoder PLL master clock PLL filter input.
60	FILO	O	Decoder PLL master clock PLL filter output.
61	CLTV	I	Decoder PLL master clock PLL VCO control voltage input.
62	PEAK	I	Inputs peak hold signal for light amount signal from RF amplifier (IC501).
63	BOTM	I	Inputs bottom hold signal for light amount signal from RF amplifier (IC501).
64	ABCD	I	Light amount signal from RF amplifier (IC501).
65	FE	I	Input focus error signal from RF amplifier (IC501).
66	AUX1	I	Input of auxiliary signal from RF amplifier (IC501).
67	VC	I	Input of middle point voltage (+1.4V) from RF amplifier (IC501).
68	ADIO	–	Not used (Open).
69	AV _{DD}	–	Power supply (+2.8V) for analog.
70	ADRT	–	Not used (Connect to +2.8V).
71	ADRB	–	Not used (Ground).
72	AV _{SS}	–	Ground terminal.
73	SE	I	Input of sled error signal from RF amplifier (IC501).
74	TE	I	Input of tracking error signal from RF amplifier (IC501).
75	AUX2	–	Not used (Connect to +2.8V).
76	DCHG	–	Not used (Connect to +2.8V).
77	APC	–	Not used (Connect to +2.8V).
78	ADFG	I	Input of ADIP dual FM signal from RF amplifier (IC501) (22.05kHz±1kHz). (TTL Schmidt input)
79	FO CONT	O	Focus control output to RF amplifier (IC501).
80	XLRF	I	Latch signal input from RF amplifier (IC501).
81	CKRF	O	RFCK clock (7.35kHz) signal output.
82	DTRF	I	Serial data input from system controller (IC801).
83	APCREF	I	Laser power setting signal input.
84	LDDR	–	Not used (Open).
85	TRDR	O	Tracking servo drive signal output (–).
86	TFDR	O	Tracking servo drive signal output (+).
87	DV _{DD}	–	Power supply (+2.8V) for digital.
88	FFDR	O	Focus servo drive signal output (+).
89	FRDR	O	Focus servo drive signal output (–).
90	FS4	O	176.4kHz clock signal output (MCLK).
91	SRDR	O	Sled servo drive signal output (–).
92	SFDR	O	Sled servo drive signal output (+).
93	SPRD	O	Spindle servo drive signal output (–).
94	SPFD	O	Spindle servo drive signal output (+).
95	FGIN	I	FG signal input from spindle motor driver (IC701).
96	TEST1	–	Not used (Connect to ground).
97	TEST2	–	Not used (Connect to ground).
98	TEST3	–	Not used (Connect to ground).
99	DV _{SS}	–	Ground terminal.
100	EFMO	O	EFM recording signal output.


IC801 SYSTEM CONTROL (CXP81960M-652R)

Pin No.	Pin name	I/O	Description
1	CLCS	O	Chip select output to real time clock (IC804).
2	XRST	O	Reset output. L : Reset
3	WRPWR	O	Laser power switching signal output.
4	TX	O	Write data transfer timing output.
5	SENSE	I	Internal status (SENSE) input.
6	LDON	O	Laser ON signal. H : ON
7	XSHOCK	I	Track jump detection input.
8	—	—	Not used (Open).
9	INLS	I	Detecting switch for internal circuit of sleding. Internal circuit : L
10	PROTECT	I	Disc write protect switch. H : Protect
11	DATA	O	Data output to remote control.
12	HOLD	I	Hold switch input (This unit). L : Hold
13	WP	I	Wake-up signal input from remote control key and this unit key.
14	OPEN	I	Detecting switch for opening and closing of the upper cover. Close : L
15	CLOCK	I	CLOCK SET switch input.
16	CLK SDIO	I	Serial clock input.
17	EVR DATA	I	Electric volume control data input.
18	PUSH JOG	I	Push JOG switch input.
19	LCD STB	O	LCD standby output.
20	CL SCK	O	Serial clock output for real time clock (IC804).
21	SDI2	I	Serial data input.
22	SYNC REC	I	SYNCHRO REC switch input.
23	D. B. B	I	DIGITAL MEGA BASS switch input.
24	XLINEDET	I	Line input detect. L : Line
25	AVLS	I	AVLS switch input. L : ON
26	XTEST	I	Test mode terminal. L : Test mode
27	XDCIN	I	DC input detect. L : DC IN
28	KANA SE L	—	Not used (Fixed at "H").
29	AM3 ON	O	This is at "H" level during external battery operation.
30	XP CONT	O	Power control output. L : ON
31	LIP ON	O	Outputs H while operating with a lithium battery.
32	XREC LED	O	REC LED control. L : ON
33	MODE2	O	Head drive (IC506) control signal output.
34	MODE1	O	
35	XRF STBY	O	Power control output to RF amplifier (IC501).
36	XLCD ON	O	LCD ON/OFF control. L : ON
37	MP	—	Microprocessor mode input (Fixed at "L").
38	XMRST	I	Microprocessor reset input.
39	Vss	—	Ground.
40	XTAL	—	System clock (12MHz).
41	EXTAL	—	System clock (12MHz).
42	CS	—	Chip Select input (Connected to +2.8V).
43	—	—	Not used (Fixed at "L").
44	LCD DATA	O	LCD data output.
45	LCD SCK	O	Serial clock output.
46	—	—	Not used (Open).
47	—	—	Not used (Open).
48	HIDCMNT	I	Voltage monitor DC input.
49	KEYR	I	Remote control key input.
50	AVss	—	Ground terminal for A/D converter.



Pin No.	Pin name	I/O	Description
51	AVREF	I	A/D converter reference voltage input.
52	AVDD	–	A/D converter power supply terminal.
53	AM3 MNT	I	AC adaptor or EXT battery detection input. L : EXT battery
54	TEMP	I	Temp meter (IC803) input.
55	KEY3	I	PLAY/REC key input.
56	KEY4	I	Key input.
57	KEY0	I	Key input.
58	KEY1	I	Key input.
59	UNREG MNT	I	UNREG voltage monitor.
60	LIP MNT	I	Voltage monitor for lithium battery.
61	FG IN	I	FG input from motor driver (IC701).
62	SLA	I	JOG dial signal input.
63	SLB	I	
64	INT SW	I	INITIAL switch input.
65	PACK IN	I	MEDIA switch input.
66	JACKDET	I	Input jack detection input.
67	OPT DET	I	Detecting input an optical input.
68	MIC DET	I	MIC jack detection.
69	XLAT	O	Latch output.
70	KEY ON	O	TRACK MARK jack input.
71	ST1 A	O	Stepping motor control signal output.
72	ST2 A	O	
73	—	–	Not used (Open).
74	—	–	Not used (Open).
75	DQSY	I	Subcode Q sync (SCOR) of digital in U-bit CD format from IC503.
76	T COUNT	I	Traverse count signal input.
77	SDI1	I	Serial data input.
78	SDO1	O	Serial data output.
79	SCK1	O	Serial clock output.
80	SQSY	I	SUB-Q/ADIP SYNC input.
81	BEEP	O	BEEP sound output control. H : BEEP sound output
82	XLIP DET	I	This is at “L” level when using the lithium battery or with no sensor switch input.
83	REFLCT	I	CD/MO discrimination switch.
84	TEX	–	Not used (Fixed at “L”)
85	XT	–	Not used (Open).
86	VSS	–	Ground.
87	VDD	–	Power supply pin (+2.8V).
88	NC	–	Not used (Fixed at “H”)
89	XCS ADA	I	Chip select input.
90	XPD ADA	O	D/A converter power down detect during recording. H : Power down
91	ST1B	O	Stepping motor control signal output.
92	ST2B	O	
93	A MUTE	O	Analog mute control. L : Mute
94	OPT CONT	O	Power supply control output for an optical input.
95	CS EVR	O	Chip select output.
96	CS NV	O	
97	SCK2	O	Serial clock output.
98	—	O	HF module control output. (Not used : open)
99	SDO2	O	Serial data output.
100	XLIP	O	Charge control. H : Charge



R-CH IS OMITTED-SAME AS L-CH



• Signal path.
 ◁ : PB
 ▷ : REC
 ▽ : MIC



Note:

- All capacitors are in μF unless otherwise noted. pF: μpF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $1/4\text{W}$ or less unless otherwise specified.


Note:



The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- Power voltage is dc 6V and fed with regulated dc power supply from external power voltage jack (J901).
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
- () : REC
- Voltages are taken with a VOM (Input impedance 10 M Ω). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path
- \Rightarrow : PB
- \Rightarrow : REC







Note:

- All capacitors are in µF unless otherwise noted. pF: µF
- 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4 W or less unless otherwise specified.
- △ : internal component.
- : B+ Line.
- : panel designation.
- Power voltage is dc 6V and fed with regulated dc power supply from external power voltage jack (J901).
- Voltages and waveforms are dc with respect to ground under no-signal conditions.
- no mark : PB
- () : REC
- Voltages are taken with a VOM (Input impedance 10 MΩ). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.

● IC BLOCK DIAGRAMS – MAIN (1/3) SECTION –
 IC501 CXA2523AR-T4




IC506 MPC18A20VM




● IC BLOCK DIAGRAMS – MAIN (2/3) SECTION –


IC804 DS1302Z




IC806 MB3800PNF




IC802 RS5RJ29261




IC807 AK93C45AV-L



● IC BLOCK DIAGRAM – MAIN (3/3) SECTION –
 IC303 AK4515-VQ




7-2. CHASSIS SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	X-4949-116-1	CASE ASSY, BATTERY		64	4-995-434-01	HOLDER (DIAL)	
52	1-782-709-11	WIRE (FLAT TYPE) (22 CORE)		65	1-475-378-11	SWITCH UNIT (WITH JOG DIAL)	
53	A-3293-759-A	SWITCH BOARD, COMPLETE		66	4-963-883-41	SCREW (M1.4), PRECISION PAN	
54	3-335-797-91	SCREW (M1.4), TOOTHED LOCK		67	4-995-432-01	HINGE, BATTERY	
55	A-3293-758-A	POWER BOARD, COMPLETE		68	4-972-529-11	KNOB (HOLD) ... (SILVER)	
56	4-964-015-31	KNOB (OPEN)		68	4-972-529-21	KNOB (HOLD) ... (BLUE) (AEP,FR,UK,HK,JEW)	
57	X-4949-660-1	BELT (S) ASSY ... (SILVER)		69	4-995-431-01	LID, BATTERY CASE ... (SILVER)	
57	X-4949-661-1	BELT (B) ASSY ... (BLUE) (AEP,FR,UK,HK,JEW)		69	4-995-431-11	LID, BATTERY CASE ... (BLUE)	(AEP,FR,UK,HK,JEW)
58	4-995-402-01	SPRING (LOCK), TENSION		70	4-995-437-01	SCREW (DAMPER)	
59	4-995-435-01	DAMPER (R50)		71	3-349-825-52	SCREW, PRECISION	
60	X-4949-114-1	CHASSIS (MAIN) ASSY		72	4-017-441-01	CUSHION (B) (AEP,UK,HK,JEW)	
61	A-3293-760-A	MAIN BOARD, COMPLETE (EXCEPT FR)		74	4-998-368-01	SHEET (OPEN) (AEP,UK,HK,JEW)	
61	A-3293-884-A	MAIN BOARD, COMPLETE (FR)		75	4-997-493-01	SPRING (LOCK), COMPRESSION	
62	4-995-436-01	SCREW (HP), STEP					
63	4-984-017-21	SCREW (1.7), TAPPING					

**7-3. MECHANISM DECK SECTION
(MT-MZR50-143)**



<p>The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.</p>	<p>Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
---	---

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	1-667-210-11	MD FLEXIBLE BOARD		121	4-963-883-41	SCREW (M1.4), PRECISION PAN	
102	4-963-883-01	SCREW (M1.4), PRECISION PAN		122	4-995-580-01	SCREW, LEAD	
103	A-3293-756-A	CLV BOARD, COMPLETE		123	4-995-586-01	GEAR (SD)	
104	1-667-690-11	CLV FLEXIBLE BOARD		124	4-972-546-01	SPRING (WORM GEAR), COMPRESSION	
105	3-338-645-31	WASHER (0.8-2.5)		125	4-963-901-01	GEAR, WORM	
106	X-4949-129-1	HOLDER ASSY		126	3-315-384-11	WASHER, STOPPER	
107	3-349-825-41	SCREW		127	4-964-564-01	SCREW (M1.2X1.6)	
108	A-3293-755-A	REC BOARD, COMPLETE		128	X-4949-127-1	CHASSIS ASSY, GEAR	
109	4-995-575-01	SHEET, INSULATING		129	X-4949-126-1	CHASSIS ASSY	
110	4-995-573-01	SPRING, TENSION		130	4-995-585-01	SPRING (LIMITER), TORSION	
111	3-704-246-13	SCREW (P1.4X2.0)		131	4-963-898-11	GEAR (WORM WHEEL)	
* 112	4-995-568-01	GUIDE, HOLDER		132	3-704-197-31	SCREW (M1.4X3.0), LOCKING	
113	4-995-572-01	SHEET, BLIND		133	3-015-033-01	SCREW (DIA. 1.4X4), PRECISION	
114	4-955-841-01	SCREW		134	4-997-228-11	SPACER (RACK SPRING)	
115	4-995-570-01	SPRING, RACK		135	4-997-172-01	SCREW (M1.4X3)	
116	4-995-567-01	SHAFT, MAIN		136	1-667-211-11	MOTOR FLEXIBLE BOARD	
Δ 117	X-4949-256-1	OPTICAL PICK-UP ASSY (KMS-280A)		M901	1-763-011-11	MOTOR (SPINDLE)	
118	4-995-578-01	GEAR (SC)		M902	A-3311-972-A	MOTOR BLOCK ASSY, SLED (SLED)	
119	X-4949-131-2	BRACKET (S) ASSY		M903	A-3320-037-A	STEPPER BLOCK ASSY (STTEPPING)	
120	4-995-571-01	SPRING, THRUST					

SECTION 8 ELECTRICAL PARTS LIST

NOTE :

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms
METAL : Metal-film resistor
METAL OXIDE :Metal oxide-film resistor
F : nonflammable
- Items marked “ * ” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- SEMICONDUCTORS
In each case, u : μ , for example :
uA.... : μ A.... , uPA.... : μ PA....
uPB.... : μ PB.... , uPC.... : μ PC....
uPD.... : μ PD....
- CAPACITORS
uF : μ F
- COILS
uH : μ H
- Abbreviation
AUS : Australian
HK : Hong Kong
JEW : Tourist
FR : French

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark
	A-3293-756-A	CLV BOARD, COMPLETE *****	
< CAPACITOR >			
C701	1-164-227-11	CERAMIC CHIP 0.022uF 10%	25V
C702	1-165-176-11	CERAMIC CHIP 0.047uF 10%	16V
C703	1-164-227-11	CERAMIC CHIP 0.022uF 10%	25V
C704	1-107-826-11	CERAMIC CHIP 0.1uF 10%	16V
C705	1-162-967-11	CERAMIC CHIP 0.0033uF 10%	50V
C706	1-162-967-11	CERAMIC CHIP 0.0033uF 10%	50V
C707	1-162-967-11	CERAMIC CHIP 0.0033uF 10%	50V
C709	1-107-826-11	CERAMIC CHIP 0.1uF 10%	16V
C710	1-109-982-11	CERAMIC CHIP 1uF 10%	10V
C711	1-107-826-11	CERAMIC CHIP 0.1uF 10%	16V
< CONNECTOR >			
CN701	1-573-927-11	CONNECTOR, FFC/FPC (ZIF) 18P	
CN702	1-573-915-11	CONNECTOR, FFC/FPC (ZIF) 6P	
< IC >			
IC701	8-759-335-44	IC CXA8048N	
< TRANSISTOR >			
Q703	8-729-427-83	TRANSISTOR XP6501	
< RESISTOR >			
R701	1-218-871-11	RES,CHIP 10K 0.50%	1/16W
R702	1-218-871-11	RES,CHIP 10K 0.50%	1/16W
R703	1-216-815-11	METAL CHIP 330 5%	1/16W
R704	1-217-671-11	METAL CHIP 1 5%	1/10W
R705	1-217-671-11	METAL CHIP 1 5%	1/10W
R706	1-216-833-11	METAL CHIP 10K 5%	1/16W
R711	1-216-864-11	METAL CHIP 0 5%	1/16W
< SWITCH >			
S701	1-762-805-41	SWITCH, PUSH (1 KEY) (MEDIA)	
S702	1-762-835-11	SWITCH, PUSH (1 KEY) (PROTECT)	
S703	1-762-805-41	SWITCH, PUSH (1 KEY) (REFLECT)	
S704	1-771-092-21	SWITCH, PUSH (1 KEY) (INITIAL)	
S705	1-572-467-61	SWITCH, PUSH (1 KEY) (INLIMIT)	

Ref. No.	Part No.	Description	Remark
	A-3293-760-A	MAIN BOARD, COMPLETE (EXCEPT FR)	
	A-3293-884-A	MAIN BOARD, COMPLETE (FR) *****	
< CAPACITOR >			
C101	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V
C102	1-162-927-11	CERAMIC CHIP 100PF 5%	50V
C103	1-135-337-11	TANTAL. CHIP 1uF 20%	6.3V
C104	1-162-964-11	CERAMIC CHIP 0.001uF 10%	50V
C105	1-164-217-11	CERAMIC CHIP 150PF 5%	50V
C106	1-110-569-11	TANTAL. CHIP 47uF 20%	6.3V
C107	1-117-919-11	TANTAL. CHIP 10uF 20%	6.3V
C108	1-119-660-11	TANTAL. CHIP 4.7uF 20%	6.3V
C109	1-117-919-11	TANTAL. CHIP 10uF 20%	6.3V
C110	1-135-337-11	TANTAL. CHIP 1uF 20%	6.3V
C117	1-119-660-11	TANTAL. CHIP 4.7uF 20%	6.3V
C118	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
C120	1-107-823-11	CERAMIC CHIP 0.47uF 10%	16V
C121	1-109-982-11	CERAMIC CHIP 1uF 10%	10V
C122	1-162-957-11	CERAMIC CHIP 220PF 5%	50V
C123	1-117-919-11	TANTAL. CHIP 10uF 20%	6.3V
C124	1-165-128-11	CERAMIC CHIP 0.22uF 16V	
C125	1-162-964-11	CERAMIC CHIP 0.001uF 10%	50V
C131	1-119-660-11	TANTAL. CHIP 4.7uF 20%	6.3V
C140	1-117-919-11	TANTAL. CHIP 10uF 20%	6.3V
C161	1-162-961-11	CERAMIC CHIP 330PF 10%	50V (FR)
C161	1-162-963-11	CERAMIC CHIP 680PF 10%	50V (EXCEPT FR)
C168	1-109-982-11	CERAMIC CHIP 1uF 10%	10V
C201	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V
C202	1-162-927-11	CERAMIC CHIP 100PF 5%	50V
C203	1-135-337-11	TANTAL. CHIP 1uF 20%	6.3V
C204	1-162-964-11	CERAMIC CHIP 0.001uF 10%	50V
C205	1-164-217-11	CERAMIC CHIP 150PF 5%	50V
C206	1-110-569-11	TANTAL. CHIP 47uF 20%	6.3V
C207	1-117-919-11	TANTAL. CHIP 10uF 20%	6.3V
C208	1-119-660-11	TANTAL. CHIP 4.7uF 20%	6.3V
C209	1-117-919-11	TANTAL. CHIP 10uF 20%	6.3V
C210	1-135-337-11	TANTAL. CHIP 1uF 20%	6.3V
C217	1-119-660-11	TANTAL. CHIP 4.7uF 20%	6.3V
C218	1-164-156-11	CERAMIC CHIP 0.1uF 25V	

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
C220	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V	C521	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
C221	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	C522	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C222	1-162-957-11	CERAMIC CHIP	220PF	5%	50V	C524	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C223	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C525	1-104-852-11	TANTAL. CHIP	22uF	20%	6.3V
C224	1-165-128-11	CERAMIC CHIP	0.22uF		16V						
C225	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C529	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C231	1-119-660-11	TANTAL. CHIP	4.7uF	20%	6.3V	C530	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C240	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C531	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C261	1-162-961-11	CERAMIC CHIP	330PF	10%	50V	C532	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V
					(FR)	C533	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C261	1-162-963-11	CERAMIC CHIP	680PF	10%	50V	C534	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
					(EXCEPT FR)	C536	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C268	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	C537	1-104-908-11	TANTAL. CHIP	47uF	20%	4V
C292	1-119-660-11	TANTAL. CHIP	4.7uF	20%	6.3V	C538	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C293	1-104-912-11	TANTAL. CHIP	3.3uF	20%	6.3V	C541	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C294	1-104-847-11	TANTAL. CHIP	22uF	20%	4V						
C295	1-119-660-11	TANTAL. CHIP	4.7uF	20%	6.3V	C542	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C296	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C544	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C301	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C545	1-104-852-11	TANTAL. CHIP	22uF	20%	10V
C303	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C547	1-104-912-11	TANTAL. CHIP	3.3uF	20%	16V
C305	1-110-569-11	TANTAL. CHIP	47uF	20%	6.3V	C548	1-104-912-11	TANTAL. CHIP	3.3uF	20%	16V
C306	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C549	1-113-682-11	TANTAL. CHIP	33uF	20%	10V
C307	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C550	1-113-682-11	TANTAL. CHIP	33uF	20%	10V
C308	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C551	1-104-912-11	TANTAL. CHIP	3.3uF	20%	16V
C310	1-164-361-11	CERAMIC CHIP	0.047uF		16V	C552	1-104-912-11	TANTAL. CHIP	3.3uF	20%	16V
C311	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C553	1-113-682-11	TANTAL. CHIP	33uF	20%	10V
C314	1-119-660-11	TANTAL. CHIP	4.7uF	20%	6.3V	C554	1-104-913-11	TANTAL. CHIP	10uF	20%	16V
C315	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C555	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C318	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C559	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C319	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C560	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C320	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C561	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C321	1-110-569-11	TANTAL. CHIP	47uF	20%	6.3V	C562	1-104-852-11	TANTAL. CHIP	22uF	20%	10V
C322	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C563	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C327	1-104-852-11	TANTAL. CHIP	22uF	20%	6.3V	C564	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V
C338	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	C565	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V
C345	1-119-661-11	TANTAL. CHIP	33uF	20%	6.3V	C566	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C346	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C567	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C359	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C569	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C359	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C570	1-119-661-11	TANTAL. CHIP	33uF	20%	6.3V
C365	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C571	1-119-661-11	TANTAL. CHIP	33uF	20%	6.3V
C366	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C574	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C368	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V						
C369	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C714	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C392	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C716	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C394	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C811	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
C399	1-107-816-11	TANTAL. CHIP	0.68uF	20%	10V	C812	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C501	1-115-169-11	TANTALUM	10uF	20%	6.3V	C813	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C504	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C814	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C505	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V	C815	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C506	1-162-965-11	CERAMIC CHIP	0.0015uF	10%	50V	C816	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C507	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C817	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C508	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V	C818	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C509	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V						
C510	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	C819	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C511	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V	C820	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C512	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C821	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C513	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C822	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C515	1-119-661-11	TANTAL. CHIP	33uF	20%	6.3V	C824	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C517	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C825	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C518	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C826	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C519	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	C827	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
						C828	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V

MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C829	1-109-982-11	CERAMIC CHIP 1uF 10%	10V	IC509	8-759-487-11	IC MB81V16405B-60PFTN-2.8	
C830	1-110-569-11	TANTAL. CHIP 47uF 20%	6.3V	IC510	8-759-487-20	IC PST9330UL	
C831	1-104-852-11	TANTAL. CHIP 22uF 20%	10V	IC702	8-759-482-07	IC MPC17A28SVMEL	
C833	1-164-156-11	CERAMIC CHIP 0.1uF	25V	IC801	8-752-894-67	IC CXP81960M-652R	
C834	1-162-927-11	CERAMIC CHIP 100PF 5%	50V	IC802	8-759-343-90	IC RS5RJ29261	
C835	1-162-927-11	CERAMIC CHIP 100PF 5%	50V	IC803	8-759-332-25	IC XC31PNS01AMR	
C836	1-162-964-11	CERAMIC CHIP 0.001uF 10%	50V	IC804	8-759-343-88	IC DS1302Z	
C839	1-110-569-11	TANTAL. CHIP 47uF 20%	6.3V	IC805	8-759-497-20	IC LA4800V-S-TLM	
C851	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V	IC807	8-759-457-68	IC AK93C45AV-L	
C861	1-109-982-11	CERAMIC CHIP 1uF 10%	10V	IC909	8-759-482-08	IC XC62EP4201MR	
C862	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V			< JACK >	
C899	1-251-641-11	ELEMENT, STORAGE		J301	1-779-881-21	JACK (MIC PLUG IN POWER)	
C901	1-107-826-11	CERAMIC CHIP 0.1uF 10%	16V	J302	1-778-179-11	JACK (2/REMOTE)	
C904	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V	J303	1-779-881-11	JACK (LINE OUT)	
C908	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V	J304	8-749-014-07	IC GP1F565R (LINE IN OPTICAL)	
C910	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V	J901	1-779-880-11	JACK,DC (POLARITY UNIFIED TYPE)	
C913	1-135-213-21	TANTAL. CHIP 3.3uF 20%	25V			(DC IN 6V)	
C914	1-104-852-11	TANTAL. CHIP 22uF 20%	10V			< COIL >	
C990	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V	L303	1-414-398-11	INDUCTOR 10uH	
		< CONNECTOR >		L304	1-414-398-11	INDUCTOR 10uH	
CN501	1-573-931-11	CONNECTOR, FFC/FPC (ZIF) 22P		L501	1-414-398-11	INDUCTOR 10uH	
CN502	1-573-362-11	CONNECTOR, FFC/FPC 22P		L502	1-414-398-11	INDUCTOR 10uH	
* CN801	1-778-170-11	CONNECTOR, FFC/FPC (ZIF) 22P		L504	1-414-410-21	INDUCTOR 10uH	
* CN802	1-778-157-11	CONNECTOR, FFC/FPC (ZIF) 9P		L505	1-412-034-11	INDUCTOR CHIP 330uH	
CN803	1-573-921-11	CONNECTOR, FFC/FPC (ZIF) 13P		L506	1-414-402-11	INDUCTOR 47uH	
		< DIODE >		L507	1-414-402-11	INDUCTOR 47uH	
D301	8-719-158-15	DIODE RD5.6S-B		L508	1-414-402-11	INDUCTOR 47uH	
D302	8-719-066-17	DIODE FTZ6.8E-T148		L509	1-414-402-11	INDUCTOR 47uH	
D303	8-719-066-17	DIODE FTZ6.8E-T148		L510	1-414-410-21	INDUCTOR 10uH	
D308	8-719-045-67	DIODE RB731U-T108		L511	1-414-402-11	INDUCTOR 47uH	
D501	8-719-421-27	DIODE MA728		L512	1-416-436-11	INDUCTOR 68uH	
D502	8-719-421-27	DIODE MA728		L513	1-414-398-11	INDUCTOR 10uH	
D804	8-719-045-67	DIODE RB731U-T108		L514	1-412-034-11	INDUCTOR CHIP 330uH	
D805	8-719-421-27	DIODE MA728		L801	1-414-402-11	INDUCTOR 47uH	
D806	8-719-421-27	DIODE MA728				< LINE FILTER >	
D807	8-719-421-27	DIODE MA728		LF901	1-416-405-21	FILTER, CHIP EMI (COMMON MODE)	
D808	8-719-047-73	DIODE HRU0302A-TR				< TRANSISTOR >	
D809	8-719-421-27	DIODE MA728		Q101	8-729-013-37	TRANSISTOR 2SC4213-AB-TE85L	
D903	8-719-158-15	DIODE RD5.6S-B		Q102	8-729-013-37	TRANSISTOR 2SC4213-AB-TE85L	
D905	8-719-066-16	DIODE RB491D-T146		Q201	8-729-013-37	TRANSISTOR 2SC4213-AB-TE85L	
		< FERRITE BEAD >		Q202	8-729-013-37	TRANSISTOR 2SC4213-AB-TE85L	
FB311	1-500-444-11	INDUCTOR 0UH		Q301	8-729-028-91	TRANSISTOR DTA144EUA-T106	
FB314	1-500-444-11	INDUCTOR 0UH		Q302	8-729-023-89	TRANSISTOR 2SJ305(TE85L)	
		< IC >		Q309	8-729-930-00	TRANSISTOR UMD2	
IC301	8-759-482-09	IC RN5RZ25BA-TL		Q311	8-729-930-00	TRANSISTOR UMD2	
IC302	8-759-252-90	IC TLV2362IPW-ELM1500		Q312	8-729-026-53	TRANSISTOR 2SA1576A-T106-QR	
IC303	8-759-439-74	IC AK4515-VQ		Q313	8-729-929-80	TRANSISTOR UMB2	
IC304	8-759-252-90	IC TLV2362IPW-ELM1500		Q314	8-729-929-80	TRANSISTOR UMB2	
IC305	8-759-481-66	IC DS1801E-014TE2		Q502	8-729-422-39	TRANSISTOR XN4404	
IC306	8-759-487-19	IC PST9322UL		Q503	8-729-930-13	TRANSISTOR UMH2	
IC501	8-752-080-95	IC CXA2523AR-T4		Q504	8-729-019-25	TRANSISTOR 2SK1467-TD	
IC503	8-752-384-47	IC CXD2652AR		Q505	8-729-930-00	TRANSISTOR UMD2	
IC505	8-759-460-34	IC MPC17A36VMEL		Q801	8-729-930-00	TRANSISTOR UMD2	
IC506	8-759-329-43	IC MPC18A20VM		Q806	8-729-031-34	TRANSISTOR 2SK2034	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
Q810	8-729-905-35	TRANSISTOR	2SC4081-R	R310	1-216-837-11	METAL CHIP	22K 5% 1/16W
Q811	8-729-927-62	TRANSISTOR	UMX1	R352	1-500-444-11	INDUCTOR	0uH
Q901	8-729-042-81	TRANSISTOR	FZT788BTC	R355	1-216-847-11	METAL CHIP	150K 5% 1/16W
Q902	8-729-026-53	TRANSISTOR	2SA1576A-T106-QR	R359	1-500-444-11	INDUCTOR	0uH
Q903	8-729-029-14	TRANSISTOR	DTC144EUA-T106	R361	1-216-825-11	METAL CHIP	2.2K 5% 1/16W
Q904	8-729-042-81	TRANSISTOR	FZT788BTC	R364	1-216-789-11	METAL CHIP	2.2 5% 1/16W
Q910	8-729-905-35	TRANSISTOR	2SC4081-R	R365	1-216-809-11	METAL CHIP	100 5% 1/16W
		< RESISTOR >		R374	1-216-845-11	METAL CHIP	100K 5% 1/16W
R101	1-218-867-11	RES,CHIP	6.8K	0.50%	1/16W		
R103	1-218-867-11	RES,CHIP	6.8K	0.50%	1/16W		
R105	1-216-837-11	METAL CHIP	22K	5%	1/16W		
R107	1-218-883-11	RES,CHIP	33K	0.50%	1/16W		
R108	1-218-843-11	RES,CHIP	680	0.50%	1/16W		
R111	1-218-891-11	RES,CHIP	68K	0.50%	1/16W		
R112	1-218-887-11	RES,CHIP	47K	0.50%	1/16W		
R119	1-216-789-11	METAL CHIP	2.2	5%	1/16W		
R121	1-218-891-11	RES,CHIP	68K	0.50%	1/16W		
R122	1-218-875-11	RES,CHIP	15K	0.50%	1/16W		
R123	1-218-855-11	RES,CHIP	2.2K	0.50%	1/16W		
R124	1-216-835-11	METAL CHIP	15K	5%	1/16W		
R134	1-216-821-11	METAL CHIP	1K	5%	1/16W		
R136	1-218-879-11	RES,CHIP	22K	0.50%	1/16W		
R136	1-218-871-11	RES,CHIP	10K	0.50%	1/16W	(FR)	
						(EXCEPT FR)	
R137	1-216-827-11	METAL CHIP	3.3K	5%	1/16W		
R141	1-216-833-11	METAL CHIP	10K	5%	1/16W		
R144	1-500-444-11	INDUCTOR	0uH				
R159	1-500-444-11	INDUCTOR	0uH				
R160	1-216-857-11	METAL CHIP	1M	5%	1/16W		
R201	1-218-867-11	RES,CHIP	6.8K	0.50%	1/16W		
R203	1-218-867-11	RES,CHIP	6.8K	0.50%	1/16W		
R205	1-216-837-11	METAL CHIP	22K	5%	1/16W		
R207	1-218-883-11	RES,CHIP	33K	0.50%	1/16W		
R208	1-218-843-11	RES,CHIP	680	0.50%	1/16W		
R211	1-218-891-11	RES,CHIP	68K	0.50%	1/16W		
R212	1-218-887-11	RES,CHIP	47K	0.50%	1/16W		
R219	1-216-789-11	METAL CHIP	2.2	5%	1/16W		
R221	1-218-891-11	RES,CHIP	68K	0.50%	1/16W		
R222	1-218-875-11	RES,CHIP	15K	0.50%	1/16W		
R223	1-218-855-11	RES,CHIP	2.2K	0.50%	1/16W		
R224	1-216-835-11	METAL CHIP	15K	5%	1/16W		
R234	1-216-821-11	METAL CHIP	1K	5%	1/16W		
R236	1-218-879-11	RES,CHIP	22K	0.50%	1/16W		
R236	1-218-871-11	RES,CHIP	10K	0.50%	1/16W	(FR)	
						(EXCEPT FR)	
R237	1-216-827-11	METAL CHIP	3.3K	5%	1/16W		
R241	1-216-833-11	METAL CHIP	10K	5%	1/16W		
R244	1-500-444-11	INDUCTOR	0uH				
R259	1-500-444-11	INDUCTOR	0uH				
R260	1-216-857-11	METAL CHIP	1M	5%	1/16W		
R302	1-216-825-11	METAL CHIP	2.2K	5%	1/16W		
R306	1-216-797-11	METAL CHIP	10	5%	1/16W		
R307	1-216-825-11	METAL CHIP	2.2K	5%	1/16W		
R308	1-216-825-11	METAL CHIP	2.2K	5%	1/16W		
R309	1-216-809-11	METAL CHIP	100	5%	1/16W		
R501	1-216-835-11	METAL CHIP	15K	5%	1/16W		
R502	1-216-835-11	METAL CHIP	15K	5%	1/16W		
R503	1-216-831-11	METAL CHIP	6.8K	5%	1/16W		
R504	1-216-859-11	RES,CHIP	1.5M	5%	1/16W		
R505	1-218-446-11	METAL CHIP	1	5%	1/16W		
R506	1-216-811-11	METAL CHIP	150	5%	1/16W		
R507	1-216-833-11	METAL CHIP	10K	5%	1/16W		
R508	1-216-817-11	METAL CHIP	470	5%	1/16W		
R509	1-216-853-11	METAL CHIP	470K	5%	1/16W		
R510	1-216-825-11	METAL CHIP	2.2K	5%	1/16W		
R511	1-216-825-11	METAL CHIP	2.2K	5%	1/16W		
R512	1-216-825-11	METAL CHIP	2.2K	5%	1/16W		
R513	1-216-843-11	METAL CHIP	68K	5%	1/16W		
R514	1-216-864-11	METAL CHIP	0	5%	1/16W		
R515	1-216-864-11	METAL CHIP	0	5%	1/16W		
R516	1-216-821-11	METAL CHIP	1K	5%	1/16W		
R517	1-216-803-11	METAL CHIP	33	5%	1/16W		
R520	1-216-841-11	METAL CHIP	47K	5%	1/16W		
R521	1-500-444-11	INDUCTOR	0uH				
R525	1-216-845-11	METAL CHIP	100K	5%	1/16W		
R526	1-216-853-11	METAL CHIP	470K	5%	1/16W		
R527	1-216-833-11	METAL CHIP	10K	5%	1/16W		
R528	1-216-821-11	METAL CHIP	1K	5%	1/16W		
R529	1-216-821-11	METAL CHIP	1K	5%	1/16W		
R530	1-216-827-11	METAL CHIP	3.3K	5%	1/16W		
R531	1-216-845-11	METAL CHIP	100K	5%	1/16W		
R536	1-218-891-11	RES,CHIP	68K	0.50%	1/16W		
R537	1-218-899-11	RES,CHIP	150K	0.50%	1/16W		
R538	1-218-895-11	RES,CHIP	100K	0.50%	1/16W		
R539	1-216-833-11	METAL CHIP	10K	5%	1/16W		
R540	1-216-857-11	METAL CHIP	1M	5%	1/16W		
R541	1-216-843-11	METAL CHIP	68K	5%	1/16W		
R542	1-218-903-11	RES,CHIP	220K	0.50%	1/16W		
R543	1-218-887-11	RES,CHIP	47K	0.50%	1/16W		
R545	1-216-845-11	METAL CHIP	100K	5%	1/16W		
R546	1-216-841-11	METAL CHIP	47K	5%	1/16W		
R549	1-216-845-11	METAL CHIP	100K	5%	1/16W		
R554	1-216-821-11	METAL CHIP	1K	5%	1/16W		
R555	1-216-817-11	METAL CHIP	470	5%	1/16W		
R559	1-216-811-11	METAL CHIP	150	5%	1/16W		
R562	1-218-887-11	RES,CHIP	47K	0.50%	1/16W		
R563	1-216-833-11	METAL CHIP	10K	5%	1/16W		
R564	1-216-843-11	METAL CHIP	68K	5%	1/16W		
R565	1-216-845-11	METAL CHIP	100K	5%	1/16W		
R566	1-216-841-11	METAL CHIP	47K	5%	1/16W		
R576	1-216-813-11	METAL CHIP	220	5%	1/16W		
R710	1-216-819-11	METAL CHIP	680	5%	1/16W		

MAIN

POWER

Ref. No.	Part No.	Description	Remark
R802	1-216-851-11	METAL CHIP	330K 5% 1/16W
R803	1-216-857-11	METAL CHIP	1M 5% 1/16W
R816	1-216-851-11	METAL CHIP	330K 5% 1/16W
R817	1-216-851-11	METAL CHIP	330K 5% 1/16W
R818	1-216-857-11	METAL CHIP	1M 5% 1/16W
R820	1-218-887-11	RES,CHIP	47K 0.50% 1/16W
R821	1-218-887-11	RES,CHIP	47K 0.50% 1/16W
R822	1-218-887-11	RES,CHIP	47K 0.50% 1/16W
R825	1-216-851-11	METAL CHIP	330K 5% 1/16W
R826	1-216-857-11	METAL CHIP	1M 5% 1/16W
R827	1-216-864-11	METAL CHIP	0 5% 1/16W
R828	1-218-911-11	RES,CHIP	470K 0.50% 1/16W
R829	1-218-899-11	RES,CHIP	150K 0.50% 1/16W
R830	1-216-851-11	METAL CHIP	330K 5% 1/16W
R831	1-216-857-11	METAL CHIP	1M 5% 1/16W
R833	1-216-857-11	METAL CHIP	1M 5% 1/16W
R834	1-216-857-11	METAL CHIP	1M 5% 1/16W
R836	1-218-871-11	RES,CHIP	10K 0.50% 1/16W
R837	1-216-851-11	METAL CHIP	330K 5% 1/16W
R838	1-218-887-11	RES,CHIP	47K 0.50% 1/16W
R839	1-218-871-11	RES,CHIP	10K 0.50% 1/16W
R840	1-218-879-11	RES,CHIP	22K 0.50% 1/16W
R846	1-218-875-11	RES,CHIP	15K 0.50% 1/16W
R847	1-216-845-11	METAL CHIP	100K 5% 1/16W
R848	1-216-845-11	METAL CHIP	100K 5% 1/16W
R852	1-218-883-11	RES,CHIP	33K 0.50% 1/16W
R853	1-216-809-11	METAL CHIP	100 5% 1/16W
R856	1-216-821-11	METAL CHIP	1K 5% 1/16W
R857	1-216-833-11	METAL CHIP	10K 5% 1/16W
R861	1-216-857-11	METAL CHIP	1M 5% 1/16W
R866	1-216-851-11	METAL CHIP	330K 5% 1/16W
R868	1-216-845-11	METAL CHIP	100K 5% 1/16W
R870	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
R873	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
R877	1-216-845-11	METAL CHIP	100K 5% 1/16W
R878	1-216-833-11	METAL CHIP	10K 5% 1/16W
R901	1-216-817-11	METAL CHIP	470 5% 1/16W
R902	1-216-833-11	METAL CHIP	10K 5% 1/16W
R903	1-216-853-11	METAL CHIP	470K 5% 1/16W
R904	1-216-845-11	METAL CHIP	100K 5% 1/16W
R905	1-216-809-11	METAL CHIP	100 5% 1/16W
R906	1-216-841-11	METAL CHIP	47K 5% 1/16W
R907	1-220-942-11	METAL CHIP	3.3 1% 1/4W
R908	1-220-942-11	METAL CHIP	3.3 1% 1/4W
R909	1-216-857-11	METAL CHIP	1M 5% 1/16W
< COMPOSITION CIRCUIT BLOCK >			
RB301	1-233-971-11	RES, NETWORK (CHIP TYPE)	47K
RB302	1-233-957-11	RES, NETWORK (CHIP TYPE)	220
RB303	1-233-969-11	RES, NETWORK (CHIP TYPE)	22K
RB801	1-233-979-11	RES, NETWORK (CHIP TYPE)	1M
RB802	1-233-976-11	RES, NETWORK (CHIP TYPE)	330K
RB803	1-233-965-11	RES, NETWORK (CHIP TYPE)	4.7K
RB804	1-233-979-11	RES, NETWORK (CHIP TYPE)	1M
RB805	1-233-976-11	RES, NETWORK (CHIP TYPE)	330K
RB806	1-233-976-11	RES, NETWORK (CHIP TYPE)	330K
RB807	1-233-979-11	RES, NETWORK (CHIP TYPE)	1M

Ref. No.	Part No.	Description	Remark
RB808	1-233-973-11	RES, NETWORK (CHIP TYPE)	100K
< SWITCH >			
S301	1-762-078-11	SWITCH, SLIDE (MIC SENS)	
S804	1-771-091-21	SWITCH, PUSH (1 KEY) (REC →)	
S809	1-572-921-11	SWITCH, KEY BOARD (CLOCK SET)	
S810	1-692-088-11	SWITCH, TACTILE (DIGITAL MEGA BASS)	
S811	1-762-078-11	SWITCH, SLIDE (AVLS)	
S816	1-762-078-11	SWITCH, SLIDE (SYNCHRO REC)	
S817	1-762-805-21	SWITCH, PUSH (1 KEY) (DOOR OPEN)	
S823	1-572-467-41	SWITCH, PUSH (1 KEY) (OPEN →) (FR)	
S823	1-572-467-61	SWITCH, PUSH (1 KEY) (OPEN →) (EXCEPT FR)	
< THERMISTOR(POSITIVE) >			
THP901	1-771-075-21	THERMISTOR, POSITIVE	
< VIBRATOR >			
X501	1-767-722-21	VIBRATOR, CRYSTAL (22.5MHz)	
X801	1-760-174-31	VIBRATOR, CERAMIC (12MHz)	
X802	1-579-886-21	VIBRATOR, CRYSTAL (32kHz)	

A-3293-758-A	POWER BOARD, COMPLETE		

< CAPACITOR >			
C801	1-117-720-11	CERAMIC CHIP	4.7uF 10V
C802	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V
C803	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C804	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C805	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C807	1-162-965-11	CERAMIC CHIP	0.0015uF 10% 50V
C809	1-115-169-11	TANTALUM	10uF 20% 6.3V
C810	1-117-720-11	CERAMIC CHIP	4.7uF 10V
C832	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C837	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C840	1-126-923-11	ELECT	220uF 20% 10V
C841	1-109-982-11	CERAMIC CHIP	1uF 10% 10V
C842	1-117-919-11	TANTAL. CHIP	10uF 20% 6.3V
C843	1-117-919-11	TANTAL. CHIP	10uF 20% 6.3V
C860	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V
< CONNECTOR >			
CN805	1-573-931-11	CONNECTOR, FFC/FPC (ZIF) 22P	
< DIODE >			
D801	8-719-988-07	DIODE RB400D	
D803	8-719-989-53	LED CL-200HR-C-TSL (REC)	
D810	8-719-988-62	DIODE 1SS355	
< IC >			
IC806	8-759-331-73	IC MB3800PNF	
IC808	8-729-039-08	IC SI6946DQ-T1	
< COIL >			
L802	1-424-675-11	INDUCTOR	33uH

Ref. No.	Part No.	Description	Remark
L804	1-414-410-21	INDUCTOR 10uH	
L805	1-414-410-21	INDUCTOR 10uH	
< TRANSISTOR >			
Q803	8-729-807-52	TRANSISTOR 2SD1623-T	
Q804	8-729-822-62	TRANSISTOR 2SB1302-T	
Q805	8-729-905-35	TRANSISTOR 2SC4081-R	
Q888	8-729-029-14	TRANSISTOR DTC144EUA-T106	
< RESISTOR >			
R801	1-216-789-11	METAL CHIP 2.2 5% 1/16W	
R808	1-216-817-11	METAL CHIP 470 5% 1/16W	
R809	1-216-827-11	METAL CHIP 3.3K 5% 1/16W	
R810	1-216-827-11	METAL CHIP 3.3K 5% 1/16W	
R811	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R812	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R814	1-218-883-11	RES,CHIP 33K 0.50% 1/16W	
R815	1-218-863-11	RES,CHIP 4.7K 0.50% 1/16W	
R867	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R875	1-216-801-11	METAL CHIP 22 5% 1/16W	
R879	1-216-809-11	METAL CHIP 100 5% 1/16W	
R880	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R888	1-216-823-11	METAL CHIP 1.5K 5% 1/16W	
< VARIABLE RESISTOR >			
RV801	1-223-994-21	RES, CARBON ADJ VAR 4.7K (DD 2.8V)	
< SWITCH >			
S818	1-762-621-21	SWITCH, PUSH (1 KEY) (BATTERY DET)	

A-3293-755-A	REC BOARD, COMPLETE *****		
< CAPACITOR >			
C401	1-107-826-11	CERAMIC CHIP 0.1uF 10% 16V	
C402	1-107-810-11	TANTAL. CHIP 33uF 20% 4V	
C403	1-109-814-11	CAP. CHIP 220PF 5% 100V	
< DIODE >			
D401	8-719-046-86	DIODE F1J6TP	
D402	8-719-046-86	DIODE F1J6TP	
< TRANSISTOR >			
Q401	8-729-024-44	TRANSISTOR 2SK2315TYTR	
Q402	8-729-024-44	TRANSISTOR 2SK2315TYTR	
Q403	8-729-024-44	TRANSISTOR 2SK2315TYTR	
Q404	8-729-024-44	TRANSISTOR 2SK2315TYTR	

A-3293-759-A	SWITCH BOARD, COMPLETE *****		
< RESISTOR >			
R844	1-218-867-11	RES,CHIP 6.8K 0.50% 1/16W	
R845	1-218-871-11	RES,CHIP 10K 0.50% 1/16W	

Ref. No.	Part No.	Description	Remark
< SWITCH >			
S801	1-572-921-11	SWITCH, KEY BOARD (ERASE)	
S802	1-572-921-11	SWITCH, KEY BOARD (END SERCH)	
S803	1-572-921-11	SWITCH, KEY BOARD (T MARK)	
S805	1-762-078-11	SWITCH, SLIDE (HOLD \blacktriangleright)	

MISCELLANEOUS *****			
3	1-801-522-21	LCD MODULE	
52	1-782-709-11	WIRE (FLAT TYPE) (22 CORE)	
65	1-475-378-11	SWITCH UNIT (WITH JOG DIAL)	
101	1-667-210-11	MD FLEXIBLE BOARD	
104	1-667-690-11	CLV FLEXIBLE BOARD	
136	1-667-211-11	MOTOR FLEXIBLE BOARD	
M901	1-763-011-11	MOTOR (SPINDLE)	
M902	A-3311-972-A	MOTOR BLOCK ASSY, SLED (SLED)	
M903	A-3320-037-A	STEPPER BLOCK ASSY (STTEPPING)	

ACCESSORIES & PACKING MATERIALS *****			
\triangle	1-467-510-31	ADAPTOR, AC (AC-MZ60A) (US,Canadian)	
\triangle	1-467-511-51	ADAPTOR, AC (AC-MZ60A) (AEP,FR)	
\triangle	1-467-512-31	ADAPTOR, AC (AC-MZ60A) (UK,HK)	
\triangle	1-467-513-21	ADAPTOR, AC (AC-MZ60) (AUS)	
\triangle	1-467-514-11	ADAPTOR, AC (AC-MZ60) (E,JEW)	
	1-475-375-21	REMOTE CONTROL UNIT (RM-MZR50)	
\triangle	1-569-007-11	ADAPTOR, CONVERSION 2P (E,JEW)	
	1-759-277-21	CASE, BATTERY (EBP-MZR4)	
	1-779-504-11	CONNECTOR, OPTICAL (AEP,FR,UK,Canadian,HK)	
	3-861-298-11	MANUAL, INSTRUCTION (ENGLISH,SPANISH, PORTUGUESE,SWEDISH,FINNISH) (AEP,E,JEW)	
	3-861-298-21	MANUAL, INSTRUCTION (ENGLISH) (US,UK,HK,AUS)	
	3-861-298-31	MANUAL, INSTRUCTION (ENGLISH,FRENCH, GERMAN,DUTCH,ITALIAN) (Canadian,AEP,FR)	
	3-861-298-41	MANUAL, INSTRUCTION (JAPANESE,CHINESE,KOREAN) (E,HK,JEW)	
	4-972-888-01	CASE, CARRYING	
	4-988-159-01	CASE, ACCESSORY (JEW)	
	8-953-218-90	HEADPHONE MDR-E838SP//K SET (EXCEPT US)	
	8-953-278-90	HEADPHONE MDR-A34SP SET (US)	
	X-3329-657-1	ATTACHMENT ASSY	

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque \triangle sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

