SONY

SERVICE MANUAL

US Model Canadian Model AEP Model UK Model E Model Tourist Model

CORRECTION-2

Correct your service manual as shown below.

: indicates corrected portion.

Page	INCORRECT			CORRECT	
83	Ref. No.	Part No.	Description	Part No.	Description
Supp-1 27	IC801	8-752-842-14	IC CXP817P40Q-1-000	8-752- <u>844-55</u>	IC CXP81740-603Q

(SPM-96047)