

Repair tips

SUBJECT: Unit runs but will not play MO intermittently: Show error code 137 or 237

DATE: 05/16/2002

MODEL (S): MZ-R500/R700/R900

Symptom: Unit runs but will not play MO intermittently. Gets a '137' or a '237' error not in the manual.

Solutions: Suspect physical impact but no obvious damage. Optical corrects the problem. This fault has been seen several times. Physical damage suspected each time.

Submitted By: Brian @ PHD Electronics Ltd.

Sony of Canada Ltd.

115 Gordon Baker Road, Toronto, Ontario M2H-3R6
NATIONAL LAB - AVIT